

Butterfly Embroidery Machine

B1501B/T Single-Head 15 Needle

Operation and Service Manual

© Copyright 2020

TheEmbroideryWarehouse



TheEmbroideryWarehouse

2

© 2020 TheEmbroideryWarehouse

PO BOX 11977 Fort Worth, Texas

All rights reserved. No part of this manual may be reproduced, transmitted, or viewed in any form or by any means without permission in writing by its publisher.

Version 1.52

Last Revision - 12/17/2020

TheEmbroideryWarehouse.com

TABLE OF CONTENTS

Table of Contents						
Ał	oout thi	is doo	cument6			
1	Gen	General Information7				
	1.1 Abo		ut the Machine7			
	1.2	Com	npatible Design Formats7			
	1.3	Туре	e of Embroidery Applications7			
	1.4	War	ranty and return policy8			
	1.5	Con	tact and technical information9			
2	Sett	Setting up your equipment				
	2.1	Inclu	uded with your equipment11			
	2.2	Gett	ting to know your machine12			
	2.2.2	1	Front View12			
	2.2.2	2	Control Panel12			
	2.2.3	3	Left View			
	2.2.4	4	Right View			
	2.3	Out	of the crate setup14			
	2.3.3	1	Unboxing14			
	2.3.2	2	Setting up stand (Complete)14			
	2.3.3	3	Setting up stand (Using Table Top)14			
2.3.		4	Placing machine on stand (Without Table Top)14			
	2.4	Sett	ing up thread rack tree			
	2.5	Sett	ing up threading tubes16			
	2.6	Sett	ing the spools17			
	2.7	Thre	eading and tensions of your machine18			
	2.8	Sett	ing Upper Thread19			
	2.8.2	1	Upper Thread Threading19			
	2.8.2	2	Upper Thread Tension			
	2.9	Sett	ing Bobbin23			
	2.9.3	1	Bobbin Thread Threading23			

TheEmbroideryWarehouse.com

2.9.2		Bobbin Thread Tensions	24
2.10	Nee	edles	26
2.1	L0.1	Recommended Needles	26
2.1	L0.2	Changing or Replacing Needles	26
3 Ho	oping	5	29
3.1	Set	ting up the tubular arms	29
3.2	Но	oping a tubular hoop	30
4 Us	Using the Control Panel		32
4.1	Abo	out the control panel	32
4.2	Bas	sic Control Panel Operations	33
4.2	2.1	Load design from USB / Memory stick	33
4.2	2.2	Load design from memory (internal memory)	33
4.2	2.3	Color Changes	33
4.2	2.4	Changing Orientation of Design	33
4.2	2.5	Centering and Tracing	34
5 Ma	laintenance		36
5.1	Oiling		36
5.1	l.1	Oil Point Breakdown	37
5.1	L.2	Oil and Lubrication Videos	38
5.2	Tim	ning and Synchronization Points	38
5.3	Ele	ctronics Specs	38
6 Glo	jlossary		
6.1	Glo	ssary	39
7 Fre	equen	tly Asked Questions	41
7.1	FAC	QS	41
8 Sp	ecifica	ations	42
8.1	Ma	chine specifications	42
9 Tro	oubles	shooting and Technical Support	43
9.1	Тес	hnical Support	43
9.2	Tro	ubleshooting	43
9.3	Erro	or Codes	44
10	Pictur	es	46
10.1	Pict	tures & Videos	46

TheEmbroideryWarehouse.com

11	Part Bo	ook47
1	1.1 Part	s Book
	11.1.1	Frame and Table Components
	11.1.2	Rotary Hook Box52
	11.1.3	Thread Cut Components
	11.1.4	Machine Head58
	11.1.5	Needle Bar Drive Components61
	11.1.6	Upper Thread Holder63
	11.1.7	Color Change System
	11.1.8	Needle Bar Bracket (1)68
	11.1.9	Needle Bar Bracket (2)70
	11.1.10	X-Axis Drive Components72
	11.1.11	Y-Axis Drive System
	11.1.12	Tension Base
	11.1.13	Automatic Winding Components80
	11.1.14	Electrical Control Components82
	11.1.15	Operating Plate
	11.1.16	Cap Drive Components
	11.1.17	Cap Base Components88
	11.1.18	Cap Frame90
	11.1.19	Thread Support92
	11.1.20	Embroidery Frame94

ABOUT THIS DOCUMENT

6

This document is to be used as a reference user's manual for the Butterfly B1501B/T – Single Head 15 Needle Embroidery Machine.

We highly encourage you to completely review the entire contents of this manual before setting up or using your embroidery machine.

To download a copy of this manual at any time, please go to:

http://www.ButterFlyEmb.com/Butterfly_Embroidery_Machine_Manual.pdf

1 GENERAL INFORMATION

1.1 ABOUT THE MACHINE

The Butterfly B1501B/T is a single head (single station) embroidery machine with 15 needles (colors). This allows the user to embroider up to one garment at one time with one needle at a time. The machine automatically color changes (as indicated or preprogrammed by the embroidery machine design). A color change is in essence selecting a different needle with a different color thread in the needle. The machine has a USB port (memory stick) that reads several different embroidery formats. The user manually loads the *pre-digitized* designs into the machine off of the USB port and/or the network when applicable.

1.2 COMPATIBLE DESIGN FORMATS

The Butterfly machine work with the following design formats all saved on a standard USB flash (thumb or memory) drive. Instruction on how to save to these formats can be found in your software user manual. If you do not have software that will write to one of the compatible formats, please go to http://www.Threadses.com to download Threads - Free Digitizing / Editing Embroidery Software.

- DST (Tajima Format)
- EXP (Melco DOS Format)

1.3 TYPE OF EMBROIDERY APPLICATIONS

The Butterfly machine is comparable with most all of the major industrial (commercial) embroidery machines. Some embroidery equipment may or may not have special equipment attached to offer additional types of embroidery. The following general list includes several applications where the Butterfly Embroidery Machine might be used. Typically to change from one type of embroidery setting to the next requires the operator to manually change out adapters.

This general list includes but is not limited to:

- Flat Embroidery Work
 - Flat embroidery work typically includes works done when the embroidery machine tabletop (removable on the Butterfly) is left on the machine. This refers to anything typically flat in nature or design such as

TheEmbroideryWarehouse.com

- Drapery
- Table Cloths
- Aprons
- Yard goods (yard referring to a measurement of fabric/material)
- Etc.
- Tubular Embroidery Work
 - Tubular Embroidery Work typically refers work that is done with the removable tabletop removed from the machine. This allows for the embroidery work to be draped down from the machine hanging from the embroidery hoop. Tubular is currently the most popular form because it makes hooping and embroidering shirts much easier. Hooping a *Tubular Frame* is general much less time consuming and easier than hooping with other types of hoops or frames.
 - T-Shirt
 - Polos
 - Pillow Cases
 - Bags
 - Back of Hats
 - Etc.
- Cap (270 degree) Embroidery
 - o Cap embroidery refers to embroidery done directly on a baseball style cap/hat
 - Baseball Caps
 - Etc.

1.4 WARRANTY AND RETURN POLICY

Below is a summary of our warranty and return policy. We highly recommend you to read the full warranty and return policy document.

Our warranty covers up to 5 years on all **non-consumable** parts and electronics one the Butterfly Embroidery Machine. Our warranty does not cover misuse or user damages. To redeem warranty repairs or service, the device must be sent back to our corporate office. Labor is covered for one year via phone support, web support (email, webcam, chat, etc.) and in-house (OUR HEADQUARTERS). Labor warranty is automatically voided if the machine is worked on by non-authorized or non-approved parties.

Returns may be accepted for up to 5 days after receiving the equipment. The equipment must be returned in its original packing, undamaged. Refund will be issued upon returning the device minus ALL shipping costs. A restocking fee typically always applies.

1.5 CONTACT AND TECHNICAL INFORMATION

9

Corporate office:

2954 SE Loop 820 Fort Worth, Texas 76140 / USA +1-817-346-7691 http://www.ButterFlyEmb.com

Mailing:

PO BOX 11977 Fort Worth, Texas 76110 / USA

Parts and Accessories:

http://www.EmbAccess.com

Electronics Repairs and servicing: http://www.PLRElectronics.com

TheEmbroideryWarehouse.com

This page intentionally left blank

2 SETTING UP YOUR EQUIPMENT

2.1 INCLUDED WITH YOUR EQUIPMENT

Included in a standard purchase of the B1501B/T embroidery machine typically includes***:

- Power Cable
- Standard Tool kit with the following
 - $\circ \quad \text{Scissors}$
 - o Tweezers
 - \circ Threading Rod
 - o Oil Can
 - o Philips Screw Driver
 - o Flat Screw Driver
 - o USB Memory Stick
 - o Basic Parts
 - o Etc.
- Single Head Stand
- Removable Table Top
- Light (typically attached to the machine)
- Border Sash
- Stand (cart)
- Table top
- Cap System
- Tubular System

*** The above list may contain items not included with your particular machine. It is highly recommend getting a complete list from your sales representative. The above list is only a generalization.

2.2 GETTING TO KNOW YOUR MACHINE

2.2.1 Front View

Butterfly B1501B/T

Embroidery Machine – Front view of our Single head 15 needle embroidery machine, shown in Figure 2-1. The machine assembled on the cart/stand. This example is with the tubular hoop attachment installed and the removable table removed.



Figure 2-1: Front view of Butterfly B1501 B/T

2.2.2 Control Panel

Control panel – The control panel is where the entire machine is controlled, shown in Figure 2-2. This includes your Stop, Start, Emergency Stop and Power button at the bottom of the machine. On the right side of the machine is the USB port for inserting a USB memory stick for inputting designs into the machine. The Speed Up and Speed Down

button are used to control the embroidery speeds of the



Figure 2-2: Control Panel

machine during operation. The recommended speed to run the machine is between 600 – 800 stitches per minute. The same buttons also double as back and forward buttons for the menu, etc.

TheEmbroideryWarehouse.com

2.2.3 Left View

Head Left Side – View looking to the left side of the embroidery machine, shown in Figure 2-3. Various motors are shown on the left side of the machine. The wiper motor control the wipers which grab the embroidery thread after the thread is cut. The reciprocator motor is what controls the arm which grabs the needle bar and moves it up and down.



Figure 2-3: Left Side of Head

2.2.4 Right View

Head Right side – View looking to the right side of the embroidery machine, shown in Figure 2-4. The color change where is used to move the head to the left or to the right (to different needles). The timing sight is a glass window you can view the timing numbers through (for setting machine parameters during maintenance). The timing

wheel moves the needle bar through its cycles from 0 to 360



Figure 2-4: Right side of head

degrees. The laser light is used to highlight the needle plate hole or, the point at which the embroidery machine needle makes penetration.

TheEmbroideryWarehouse.com

2.3 OUT OF THE CRATE SETUP

If your equipment has been shipped to you in a crate then there are certain steps you will need to take to uncrate and setup. The steps may vary from machine to machine and crate to crate.

2.3.1 Unboxing

https://www.youtube.com/watch?v=CBxDQSOzCcs&t=17s

2.3.2 Setting up stand (Complete)

https://www.youtube.com/watch?v=kt5vlsOifEE&t=212s

2.3.3 Setting up stand (Using Table Top) https://www.youtube.com/watch?v=Kwj06xFSeKU

2.3.4 Placing machine on stand (Without Table Top)

https://www.youtube.com/watch?v=QPa10_AF5Cs

2.4 SETTING UP THREAD RACK TREE

Assembly of the Thread Rack (also known as the Threading Tree) – See Figure 2-5. The thread rack is the part of the machine which includes the first set of tension knobs. The primary function of the thread rack is to smoothly unwind thread off of the spool of thread.

Step 1 – Screw Thread Stand Shafts (2 pcs) in by hand into threaded holes A and B on the Thread Stand.

Step 2 – Tighten thread shafts using the flat adjustor C on each shaft with a wrench.

Step 3- Place the Thread Rack/Tree onto thread stand shafts with the knobs of the thread rack facing towards the head (front most part of the machine)

Step 4 – Tighten Allen screws on top of the thread rack.



Figure 2-5: Thread Rack

2.5 SETTING UP THREADING TUBES

Assembly of the threading tubes. – See Figure 2-6. The primary functions of the thread tubes are to keep the threads from raveling together under wind, etc.

Step 1 – Insert a Thread Tube Joint (end of a Thread Tube) into the top U-SLOT. Start by inserting one end of one tube in U-Slot A1. A1 is located on the Thread Rack.

Step 2 – Insert the other end of the Thread Tube into A2. A2 is located on the machine head, on the Tension Knob Base.

Step 3- Proceed by installing each thread tube in the same manner.



Figure 2-6: Threading Tubes

2.6 SETTING THE SPOOLS

The Butterfly B1501B/T is a 15-color machine meaning it can hold up to 15 different spools of thread. Generally, most users will use 15 different colors of thread designating at least 6 of the colors for basics such as white, black, red, blue, green, yellow, etc. There are various brands and types of threads. The most common types are **Rayon** and **Polyester**. Rayon is a softer but weaker thread. Typically, polyester (or "poly") is recommended due to its strength which also reduces thread breaks.

Step A – Begin by placing 15 spools of thread on the thread stand. Refer to Figure 2-7.

Step B – Take the first spool (1) thread and pass it through eyelet '2' in the image followed by '3' then '4'.

Step C – Take the second spool (5) thread and pass it through eyelet '6' in the image followed by '7'.

Step D - Take the third spool thread (8) and pass it through eyelet '9' in

the image

Step E – Continue with the next spool

in sequence (to the right of spool 1). Continue till the entire thread rack is threaded.

You can choose to thread the tension knob while threading the thread rack or, wait till the entire thread rack is threaded and then thread the rest of the machine (proceeding pages).



Figure 2-7: Thread Stand and Spools

2.7 THREADING AND TENSIONS OF YOUR MACHINE

Be sure you have already completed the previous sections before proceeding. Proper threading and **tensions** of your embroidery machine are essential to production, thread breaks, and final embroidery quality. Without properly threading your machine and setting the correct tensions per spool, needle and bobbin, your machine may not run. It is very important that the threading tracks and tensions are constantly checked.

2.8 SETTING UPPER THREAD

2.8.1 Upper Thread Threading

The upper thread refers to the thread that is seen on the top of the embroidered item. The upper threading track is shown in Figure 2-8. An **upper thread break** typically refers to when the current spool of thread that is embroidering has broken. Upper thread is also physically located at the top of the machine whereas the lower thread (bobbin) is located towards the bottom. Upper thread is the common spool of thread used to embroidery designs.

Video https://www.youtube.com/watc h?v=DvGIU2 -yLo

Refer to Figure 2-9 to thread.

Step A – First complete

the section "Setting the threads".



Step 1 – Insert the first

thread into the eyelet of the pretension knob. The pretension knob is the one at the very top of the machine and is the first tension knob the thread passes through

Step 2 – Place the thread in between the 2 disks of the pretension knob going to the right.

Step 3 – Detach the top of the thread tube and place thread through U-Slot

Step 4/5/6 – For this step you will need the **threading rod**. The Threading Rod is a narrow piece of plastic approximately 2 feet long about the width of a pencil tip that comes with the standard tool kit. If you do not have a threading rod, you can also use a guitar string or anything similar. On the end of the threading rod, there is a cut out notch. Insert the threading rod from the bottom of the threading tube, notch end first. Pass the threading rod through the entire threading tube until the notched end comes out. Attach the thread to the notch and (5) pull the other end of the threading rod back out of the threading tube so that the thread is completely through the tube. (6) Attach both ends of the threading tube back onto the machine.



Step 7 – Pass the thread under the thread guide. The thread guide is a piece of metal loosely attached to the machine by a screw and spring. The function of the thread guide is to unravel threads that might still be raveled and to keep threads going straight in their designated paths.

Step 8 – Pass the thread through the main tension knob in the same manner as it goes through the pretension knob

Step 9 – Place thread to the left of the guide rod

Step 10 – Pass the thread thru the next guide hook directly

under the tension side. Below this guide hook is a rotary wheel.



Figure 2-9: Thread direction

The rotary, or Thread Break wheel, is used to detect thread breaks. If your machine is giving false thread breaks, first check that this wheel is properly threaded. If this wheel is properly threaded, check the entire thread track for any mis-threading.

Step 11 - Place the thread to the left and then under the guide pin located directly to the left of the rotary wheel. Then bring the thread back over the top of the wheel and then to the right, and the back down and to the left of the next thread guide pin.

Step 12 – Bring the thread down and place thread under the next thread guide.

Step 13 – Open the head case cover. To the right of the machine behind the cover, on the head, there is a lever that goes up and down. Push the lever down as far as it goes. When you do, you will see several (12) small wires/springs. These are known as the *Check Springs*.

Step 14 – Place the thread to the right of the right most cylinder rod where check springs come out of when the check spring lever is pressed down. Place the thread through the check spring eyelet from the right to the left. Bring the thread back up to the left of the leftmost rod corresponding to the current thread you are threading. Move the lever so that the checks springs go back up all the way and then bring it back down about 1mm to give the springs a little bit more spring than if they were all the way up. Not placing the check springs in the correct position will cause trimming problems and problems when changing colors.

Step 15 – Bring the thread back up about 3 inches into the take up lever eyelet.

TheEmbroideryWarehouse.com

Step 16 – Bring the thread back down, past the check spring to the bottom of the head and through the last thread guide/eyelet

Step 17 - Place the thread through the needle eye from the front to the back. It is recommended that you cut the thread at a 45 degree angle to give it a point. Once you cut the thread, use your fingers to straighten out the end. Hold the thread with your index and thumb leaving about $1 - 1\frac{1}{2}$ inches out keeping the thread at straight as possible as you pass it through the needle. Once thru the needle, pass it through the needle bar hole.

Step 18 – Place the thread in between the long spring at the bottom of the machine. There is no need to wrap it in the spring and it is recommended placing it into the spring gently without much tension. The spring is only used to temporarily hold the thread. Cut the thread at the end leaving about 1/3 inch extra.

Step B – Continue with the next spool of thread, threading in the same manner as the previous thread.

Further examples are shown on the next page.

2.8.2 Upper Thread Tension

The upper thread tension refers to how tense or tight the thread feels when you pull it through the very last thread guide eyelet when the thread is properly threaded. There are many metrics for measuring this. However, the final metric usually just depends on what the final embroidery looks like.

Video - https://www.youtube.com/watch?v=QUhrdECHOWI

Upper thread tension is completely different between one cone and the next and the tensions change as the thread is used. Therefore, the tensions must constantly be checked. Because the B1501B/T has 15 needles and only one bobbin, it is always best to preset the bobbin tensions (next section) first and then change the upper threads to conform to the bobbin tension. In other words, once the bobbin is set, it should not be adjusted much. Each time the bobbin is changed, it may need to be set again. The operator should always recheck bobbin tensions when changing the bobbin (next section).

When pulling the upper thread from the final thread guide eyelet hole (NOT through the needle), the tension on the thread should feel about the same as if the other end of the thread was tied to 3 US Quarters (\$0.75), being dragged across a smooth surface. Generally you should start with tightening both tension knobs at about 50% and then slowly adjusting from there. Once everything is set, you should only adjust with the second tension knob located on the tension base. Minor adjustments during and after embroidery will be required and should only be done with this second knob.

When the machine is embroidering (assuming the bobbin tension is set) you can visually tell if the tensions are set or need adjusting. It is common (and required) to make minor adjustments often. If the thread appears to be loopy then the tension knob needs to be tightened. Typically it takes about ½ turn to make even a slight difference. If the thread appears too tight and/or there are a lot of thread

TheEmbroideryWarehouse.com

breaks, then the tensions need to be loosened. It is recommended during the first run of a design to slow the machine speed down as slow as possible and make minor adjustments to the tension while slowly speeding the machine up until the tensions are correct. If bobbin thread is coming up on the top of the embroidery then the upper thread may be too tight assuming the bobbin is set correctly. If the bobbin is not set correctly, then the bobbin might be too loose.

There are several other ways to test tensions. One is referred to as the 'H' or 'l' or 'Column' test. In this test, once the embroidery is completed, look underneath the embroidered item. Columns of embroidery such as the column of an 'l' should be 1/3 bobbin with 1/3 thread on each sides of the bobbin.

- If the bobbin is correctly set
 - \circ Too much bobbin (more than 1/3 of the column)? Loosen upper thread
 - Too little bobbin (less than 1/3 of the column)? Tighten upper thread
- If the bobbin is not set
 - \circ Too much bobbin (more than 1/3 of the column)? Tighten bobbin
 - \circ Too little bobbin (less than 1/3 of the column)? Loosen bobbin

2.9 SETTING BOBBIN

2.9.1 Bobbin Thread Threading

The B1501B/T uses style 'L' bobbins and bobbin cases which are also known as Standard Bobbins. We recommend using pre-wound polyester bobbins with cardboard sides. The bobbin is located inside the bobbin case and is near the bottom of the machine under the needle plate.

Video -

https://www.youtube.com/watch?v=PvE MWFMaEoY

The bobbin should be cleaned and replaced regularly to ensure proper tensions. Lint typically clogs the bobbin case which will produce variations in tensions and poor embroidery quality. It's a good indication that it's time to replace the bobbin case if the bobbin pulls out of the bobbin case rough after the case has been cleaned. Because bobbin cases are so inexpensive, it is recommended to

purchase new ones rather than replace or



Figure 2-10: Bobbin view



Bobbin should spin clockwise when pulling the thread from the bobbin case

Figure 2-11: Bobbin direction

repair used ones.

To remove the bobbin case from the **hook** of the machine, pull the bobbin case handle while extracting the case. When inserting the bobbin case back into the hook, make sure that the handle is pointing straight to the right. Do not pull the handle when inserting the case back into the hook.

To thread your bobbin into the bobbin case, follow the following steps.

Step 1 – Insert the style 'L' pre-wound standard cardboard sided bobbin into the bobbin case.

Step 2 – Insert the bobbin thread into the slot/notch on the side of the metal bobbin case.

Step 2/B – When pulling the bobbin thread through the notch, the bobbin should spin clockwise when looking at the side/top of the bobbin. If it is not spinning clockwise, remove the bobbin and flip it over.

Step 3 – Pull the bobbin thread through the notch and under the hook located right by the notch.

Step 4 – Place the thread under the pig tail of the bobbin case. Be sure that the bobbin thread passes from the bottom opening of the pig tail and exits for the very top and not from the side of the pigtail.

Step 5 – Pull the bobbin thread out about 6 inches while checking tensions (next section). Adjust if needed.

Step 5/B - Always check tensions on the bobbin when replacing it. The bobbin lasts approximately 32,000 stitches. Bobbin tensions might vary from bobbin to bobbin and the tension does change as the bobbin is used.

2.9.2 Bobbin Thread Tensions

The bobbin thread tension is typically considered much more important that the upper thread tension because all 12-15 needles depend on the tensions of the bobbin in order to embroidery properly. It is important to set the bobbin tensions one time and try not to adjust it per color but rather adjust each other color/needle to conform to the bobbin.

The bobbin tensions might need to be changed when replacing the bobbin and should be checked regardless. The operator should check the tensions of the bobbin after each run by looking at the bobbin of the final embroidery product for excess or shortage of bobbin thread. Generally, on a column stitch 1/3 of the column



should be bobbin thread and the other 2/3 upper thread.

Video -

https://www.youtube.com/watch?v=j7L9R22FuNw

Figure 2-12: Bobbin tension adjustment

An adjuster screw is located on the tension spring. Next to the adjuster screw is a fixed screw that holds down the tension spring. This fixed screw should never be touched. Tightening (turning clockwise) will tighten the tension of the bobbin. When tightening the bobbin, less bobbin thread will show underneath the final embroidered item. Loosening (turning counterclockwise) will lessen the bobbin tension. When loosening the bobbin, more bobbin thread will show underneath the final embroidered item. The bobbin tension should be set about the same at the upper thread tension. The same example of the 3 quarters (\$0.75) can be applied. Another way to check tension is to hold the bobbin thread and drop the bobbin case. The case should fall approximately 1 - 3 inches. If it falls too far, the tensions need to be tightened. If it falls too short, tensions will need to be loosened. However, that is only an example and tensions will variate from bobbin to bobbin and from bobbin case to bobbin case. The only way to set the tension accurately is by eye, based on the final embroidery quality.

*Note - If you are using a bobbin case tension gauge the approximate setting should be between 25-35 grams

2.10 NEEDLES

2.10.1 Recommended Needles

The standard needle to use on the Butterfly Embroidery Machine is a 75/11. Different needles may be recommended for different applications, such as leather work or silk, however generally we always recommend 75/11

Changing out needle sizes MAY require hook timing changes.

There is a lot to know about needles. We recommend the reader study all about needles before proceeding. There is a good article at - http://wiki.embroiderymachine.com/index.php/Embroidery_needles

2.10.2 Changing or Replacing Needles

When a needle breaks, it is required that you find the broken pieces. If not, the broken shards can scratch your hook or even lock up the machine entirely. If you cannot find the missing pieces, it is recommend blowing the entire hook area off with compressed air, in attempts to blow and other pieces away.

Video - https://www.youtube.com/watch?v=1X-O4-0J0xY

Once you have cleansed the area of any broke needles, the next step it to remove the broken needle. To change out a broken needle, locate the screw above the needle. Slightly loosen this screw until the needle can be pulled down. DO NOT loosen this screw too much or the entire needle bar assembly will come apart. Replace the broke needle with a same sized needle. Ensure that the SCARF of the needle is towards the back and that the eye of the needle is straight through. You must also ensure that the lint hole is clean and the needle goes all the way through. If the scarf it not towards the back, the machine will not run. Likewise, if the eye of the needle is not perfectly straight, you might have issues.



TheEmbroideryWarehouse.com



Figure 2-13: Replacing a needle

This page intentionally left blank

3 HOOPING

3.1 SETTING UP THE TUBULAR ARMS

The *tubular arms* are what hold the *tubular hoops* onto the machine. The tubular arms attach to the machine onto the *pantograph*. The tubular setup is the most common type of embroidery used on these types of machines. The tubular system utilizes the tubular hoops. The tubular system is most common because it's a

much quicker and easier way to hoop.

To use the tubular system, you will need to first install the tubular arms if they have not already been installed. To install the tubular arms, start by sliding the left tubular arm into the pantograph into one the slots on the left side of the pantograph (1). There are several slots on the pantograph for different size of hoops. It does not

2) Screws (2 pcs) Left Tubular Arm Pantograph Left Tubular Left Tubular 5) Screws Arm Spring Tab (2 pcs) **Right Tubular Arm Right Tubular** Arm Spring **Right Tubular** Tab **Hooped Garment** Figure 3-1: View of tubular arm system

matter which slots are uses as long as the hoop

will fit once both arms have been installed. (2) Slightly tighten the 2 screws on the tubular arm, onto the pantograph. The next step will be to select the hoop size you would like to use (3). Many embroidery machines such as the Butterfly will accept large, medium and small hoops. Large hoops are overall larger from the far left tab to the far right tab where as small hoops are smaller from one tab to the next. On standard size hoops (which might be 9cm, 12cm, 15cm, 18cm, etc) the length from one tab end to the next is 360mm. Once you select the hoop size, measure the hoop from tab to tab. Next install the right tubular arm (4) in the slots on the pantograph the same distance away from each other as the length of the hoop. Slightly tighten (5) the 2 screws on the tubular arm. It is recommended that you then place the hoop into the tubular arms to ensure it fits correctly and that the arms are not at an angle. On each of the tubular tabs, there are sides that have beveled ends. These beveled ends slide into the tubular arm springs at a 30 - 45 degree angle. Place the hoop into the tubular arms under the tubular arm springs. It is not necessary to have anything hooped into the hoop at this time. Check that the arms are not angled and then tighten the 4 tubular arm screws (2) & (5).

3.2 HOOPING A TUBULAR HOOP

Tubular hoops are the most common type of hoops used in commercial embroidery machines. They are very easy to hoop compared to the alternatives and are ideal for embroidery on assembled

goods such as shirts, etc. Embroidery on unassembled goods (raw fabric) is typically best done with other types of hoop systems but most all embroidery done commercially will be on assembled garments. There are many guides available on the internet and in other embroidery training manuals that explain the best way to hoop certain items depending on sizes, sex, type, etc. of the garments. This manual will not get into the techniques and it is recommended that the operator search on the



Figure 3-2: Example of tubular hoop

internet for further training. However, when using a tubular hoop as shown the outer ring (piece without the metal tabs) goes inside or under the garment. For example, on a t-shirt the outer ring will go inside the shirt around the area that is to be embroidered. **Backing** or **Stabilizer** is then place on top of the outer right in between the garment. The top part of the hoop is then place on top of the garment, inside the outer ring. The top part of the hoop includes the beveled tabs. The beveled part of the tab will always be on top. The garment should be hooped so that the final embroidery imaged is parallel with the beveled tabs.

This page intentionally left blank

4 USING THE CONTROL PANEL

4.1 ABOUT THE CONTROL PANEL

The control panel for the Butterfly Embroidery Machine is relatively easy to use. The control panel has a lot of uses that on a normal basis will never be used. We recommend that you become familiar with all the buttons and features but, you can also refer to the Cheat Sheet to find all you need to operate the control panel. Please refer below to the general layout of the control panel.



Figure 4-1: Butterfly touch screen control panel

4.2 BASIC CONTROL PANEL OPERATIONS

Generally, there are very few operations needed to run the Butterfly embroidery machine. We will simplify the learning process by only showing the Basic operations on the control panel in this section and show further advanced (but rarely used) operation on another section.

4.2.1 Load design from USB / Memory stick

The first step to embroidering a design is to load it into the Butterfly control panel. You will need to save your design from your PC onto a memory stick. The standard format is the Tajima DST format. Please refer to your software manual on how to save the designs as DST.

Once the design is saved onto the stick:

- 1. Insert USB in 1 of the 2 ports on right side of the display. Wait for a beep.
- 2. On screen 1, press the yellow flower button to access USB memory.
- 3. Select your desired design
- 4. Press check mark on dialogue box.
- 5. Enter design name using number pad.
- 6. Press check mark to transfer design to machine memory. Wait for a beep.

4.2.2 Load design from memory (internal memory)

Once the design is loaded off the USB stick (see previous tutorial) and on the Butterfly internal memory, then it can be loaded to embroider.

- 1. On screen 1, select desired design off machine memory. 8 are displayed at a time.
- 2. Use arrow buttons to change to the next design page if not on page 1.
- 3. Once desired design is highlighted, it has been loaded from machine's memory.

4.2.3 Color Changes

Once the design is confirmed you can program color changes.

- 1. On screen 3, colors are displayed in descending order by which they are stitched.
- 2. Colors are assigned a number that correspond to the thread colors on thread tree.

3. Press desired number to assign a needle. Once selected, it will automatically move to the next color in sequence.

4. Repeat until all required needles have been assigned.

4.2.4 Changing Orientation of Design

You can change the orientation, (mirror/rotate) by performing the following.

- 1. On screen 2, locate the "P" button.
- 2. Press the button to change to desired orientation.

4.2.5 Centering and Tracing

You can center and then trace the design by performing the following.

- 1. On screen 4, use arrow buttons to move design to desired position in hoop.
- 2. Press the arrow button in the center to change movement speed.
- 3. Once in desired position, press yellow button with magnifying glass.
- 4. You can trace design using either one of two buttons

5. The trace button with a needle and dotted box will trace a box around the design giving you the general area where the design will be.

6. The trace button with a needle and dotted circle will trace around the edge of your design giving you an exact area of where the design will be.

7. Once traced, use the arrow buttons to move design to desired location.

This page intentionally left blank

5 MAINTENANCE

5.1 OILING

To ensure your Butterfly Embroidery Machine lasts a long and healthy life, it is recommended to

oil the machine when required. Although it is recommend oiling the machine, it is highly discouraged to over oil the machine as the oil can accumulate over electronics, the garments, and other parts that are not designed to be oiled. It is also not recommended to oil parts not specified in this guide. Standard sewing or embroidery machine oil should be used. It is recommended to oil the machine after each shift to give the oil time to settle. When starting the machine at the next shift for the first time, it is recommended to sew a sample run and to sew each run using Solvy. Solvy helps to catch any excess oil from dripping on and staining the garments.



Figure 5-1: Needle bar oil locations

A) – Needle bars – Once every (20) hours of embroidery. Oil each bar through the opening. Do not place more than one drop per bar per 8-hour shift. There is a felt piece inside that head that



Figure 5-2: Rotary hook oil location

absorbs the oil and lubricates the shafts.

B) – Rotary Hook – Once every (4) hours of embroidery. It is recommended to oil the hook once at the beginning of the day and then once each (4) hours after. The oil point of the hook (basket that holds the bobbin case) is at the very top of the hook directly under the needle plate. It is not necessary to remove the needle plate if the oiler has a stray. The oil goes between the inner basket that stays stationary and the outer part that spins during embroidery. You will see the hook point at the bottom. Turn the hand-wheel on the right side of machine to move the hook

TheEmbroideryWarehouse.com
point to the 10 o'clock position. This will place the top of the raceway at about 9o'clock. Place one drop at top of race at side of basket. Next, press the stop button. This will cycle the machine to a proper head up position.

Do not place more than one drop per needle bar per 8-hour shift. It is recommended to remove the bobbin case when oiling and run a few trims without the bobbin in the case to circulate the oil. If your embroidery machine start to make a constant clicking sound it is usually due to a lack of oil on the hook.

C) – Upper Head Assembly (Reciprocator Shaft) - Once every (16 - 32) Hours of embroidery. The Reciprocator shaft is what the reciprocator rides up and down on. The shaft is not easily accessible directly from the front of the machine so, you must access it from the sides through troughs on the head. To access these troughs, either move the head all the way to needle number 1 or to needle number 12. If you are on needle number 1, the trough will be accessible from the right side of the head. If you are needle number 12, the trough will be accessible from the left of the

head. A couple drops should fill the trough. Move the head to the opposite and place a couple more drops on that opposite side.

D) – Oil Stickers – As indicated on the sticker. There are several oiling stickers/holes noted on the machine.
These oiling points should be oil as often and as much as noted on the stickers.

5.1.1 Oil Point Breakdown



Figure 5-4: Reciprocator shaft oil location



Figure 5-3: Main shaft oil location

A) – One drop once every (20) Hours of embroidery

- B) One Drop once every (4) Hours of embroidery
- C) One to two drops on each size once every (16 32) Hours of embroidery
- D) As indicated on sticker

5.1.2 Oil and Lubrication Videos

https://www.youtube.com/watch?v=UwXsoL9htPw

https://www.youtube.com/watch?v=mPhqEmWcV8E

5.2 TIMING AND SYNCHRONIZATION POINTS

There are several important timing points on your Butterfly Embroidery Machine. Remember when working with your machine; be sure to disconnect it from the power source while turned off.

Needle Depth – The needle depth is set at 180 degrees using a scratch gauge

Video - https://www.youtube.com/watch?v=bdD4_2K3UXE

Hook Timing – The Hook Timing is set at 200 degree

Video - https://www.youtube.com/watch?v=iWRrzCqGK3g

Stop Position – The Hook Timing is set at 100 degree

Video -

https://www.youtube.com/watch?v=MxaBwvfVRak&lc=z13hijzw1wy2dblze04cgphj0tieudlrooc0k

5.3 ELECTRONICS SPECS

The Butterfly embroidery machine is designed to work with either 110/220. In the United States we always provide a standard 110 cable which, is designed to plug into your standard 110 outlet. Power protection, such as surge protectors, are highly recommended.

6 GLOSSARY

6.1 GLOSSARY

- **Backing** Foundation used to stabilize and keep garment flat. Most backings are paper like.
- **Bobbin** Thread used to tie a knot under the embroidery garment which holds down the upper thread
- Bobbin Case Holds the bobbin
- Check Springs Spring used in threading track which removes whiplash during embroidery
- **Consumables** Consumables are parts used on the machine such as hooks, needles, and bobbin cases, etc. that are to be replaced on a regular basis of normal operation.
- **Digitized(ing)** Digitizing (in embroidery) is the act of converting a logo, design, symbol, etc. into an embroidery file readable by embroidery machines and software. A digitized design is one that has all stitches, color changes, trims, etc. programmed in so that the embroidery machine.
- Hook Part which ties thread onto the bobbin and makes the embroidery stitch
- **Non-consumables** –Non-consumables are parts that are not designed to be replaced on a general basis such as motors, shafts, etc.
- **Pantograph** Device on machine that moves hoop in the X and Y direction (left, right, up and down)
- **Polyester** Type of textile. In embroidery machines, its typically a stronger thread type than Rayon
- **Pre-digitized** A design that has already been digitized.
- **Rayon** Type of textile. In embroidery machines, its typically a stronger thread type than Polyester
- **Solvy** A plastic like sheet sometimes used on top of embroidery very similar to cellophane. Used to add more foundation on the embroidery. Typically dissolves under water.
- Stabilizer See Backing
- Tensions In embroidery, typically refers to how tight the thread feels when pulling it through a threaded machine or through the threaded bobbin. Improper tension will cause both false and actual thread breaks, and poor final embroidery quality among many other problems.
- **Threading Rod** Used to thread embroidery thread through the embroidery tubes.
- **Topping** Used on the top of a garment such as Solvy.
- **Tubular Arms** Arms that attach to the pantograph. The tubular hoops then attach to these arms
- **Tubular Hoop/Frame** A special type of hoop consisting of a plastic ring and another plastic piece that goes into this ring. This hoop has a metal clip which speeds up the process of loading the hoop into the machine.
- **Upper Thread Break** Typically refers to the current spool of thread that is embroidering, has broke.

- Wash-a-Way – See Solvy

7 FREQUENTLY ASKED QUESTIONS

7.1 FAQS

 How does the Butterfly B1501B/T compare to other commercial/industrial embroidery machines? The Butterfly B1501B/T will benchmark against any other machine in its class. The final embroidery quality is just as good as any other machine run under the variables (design type, thread quality, etc).

8 Specifications

8.1 MACHINE SPECIFICATIONS

Listed below are common specifications of the Butterfly B1501B/T embroidery machine

Belts	Italian	
Bobbin Size / Style	Size / Style 'L' or Standard. Prewound polyester recommended	
Cap System	270 Degree	
Color Changes	Automatic or Manual	
Dimensions	Approximately 3' x 3' x 3' without stand	
Display	8 x 4" Color LCD Display	
Embroidery Area	40cm x 50cm ~(15in x 16 in)	
Flat Embroidery	Yes	
Heads	1	
Input	USB / Network (on certain models)	
Languages	English / Español (Spanish)	
Make	Butterfly	
Memory Capacity	16,000,000 Stitches or 500 designs	
Model	B1501B/T	
Needles	15	
Needle sizes	Standard 75/11 titanium for most applications but works with most any industrial	
(recommended)	embroidery machine type. Different needs recommend on different applications	
	such as leather goods, etc.	
Oil Type	Standard sewing/embroidery machine oil	
Power	110W factory. 220w available on order.	
Reciprocator	Pulse Motor	
Driver		
Solenoids	Japanese	
Speed (max)	1200 (Stitches/Minute)	
Table Top	Removable	
Trace	Yes	
Trimmers	Yes	
Tubular	Yes	
Weight	Approximately 100kgs (~220lbs)	
Wiper Driver	Pulse Motor	

9 TROUBLESHOOTING AND TECHNICAL SUPPORT

9.1 TECHNICAL SUPPORT

Please direct all technical questions to <u>support@butterflyemb.com</u> or by creating a support ticket by emailing <u>support@tewh.com</u>

You may also try our live support by going to <u>http://www.ButterFlyEmb.com</u> and clicking the LIVE SUPPORT icon.

9.2 **TROUBLESHOOTING**

Symptoms	Resolution
False thread breaks	-Ensure the machine is properly threaded.
Noise – Clicking Sound	-Oil Hook
Power up – Machine does not turn on	-Ensure that the power cord is securely attached to a 110V outlet and that the 110V outlet is outputting power.
	-Check fuses.
Thread Breaks	-Poor quality or old thread
	-Timing issue
	-Dull, bent, burred, etc needle
	-Check for any burs in thread track (eyelets, etc)

9.3 ERROR CODES

EMD Light not on but Dull Darl	The surrent embraidery nettern has not been
EIVID LIGHT HOL OH DUL PUILBAL!	me current emprotery pattern has not been
	queued. Press the red button with the needle
	emplem on the bottom left of the screen. The
	message "Confirm emb?" should appear on screen.
	Press the check mark to queue embroidery pattern.
Stop not in place!	The main shaft has to be at 100 degrees. Please
	move the main shaft manually, or use the red STOP
	key to ask the machine to move the motor
	automatically (if that software option is active,
	which it is by default). To move it manually, push
	the large black knob in and turn it to the left, and
	either look through the small glass portal or watch
	the LED light at the bottom of the control panel that
	says 100, until the light turns on.
Trimming not in place!	The trimming knife (movable knife) might be stuck
	and did not return to its resting position. Please
	press the red STOP button to ask the machine to
	attempt to move it home. If it still cannot move.
	then check if any threads are causing it to jam, and
	remove all thread pieces and clean the area. If it is
	still jammed, remove the needle plate and inspect.
Needle Position Abnormall	The head of the machine is not perfectly centered
	over one of the 12 color change locations. Please
	turn the small knob of the color change motor, to
	manually move the head left and right. When you
	are on a valid location, then one of the LED lights at
	the better of the centrel papel will light up, the
	light with a picture of three poodles. Also, on the
	right with a picture of three needles. Also, on the
	graphical screen at the top right, there will be a
	colored square indicator that changes from 1-12 if
	centered, or a question mark "?" if the head is in-
	between colors.
Color change time out!	The color change motor mechanically jammed
	while trying to move the head to a different needle.
	Please locate the cause of the jam and clear it, then
	move the head manually by turning the color
	change motor knob, to check if cleared.
Thread break detected!	The thread broke while sewing and no more thread
	is being pulled. If the thread is not broken, then the
	wheel sensor is not spinning or not spinning
	enough, or sensitivity is set too high in software.
	Check if the thread is running smooth and through
	every part of the upper thread area.
Back to head!	The machine was asked to back up stitches all the
	way to the first stitch, and it cannot back up any

	more.
External media is not inserted!	The USB stick is not plugged in or not initialized yet. Some USB flash drives take a few seconds to initialize, please inspect the bottom right of the control panel to see if the USB symbol is lit up. Also, some USB sticks are very wide and that can
Main motor over time!	interfere with plugging in the USB stick all the way. The main motor is not moving, possibly because of a mechanical jam. Please check if the needle hit anything (such as the hoop), and also spin the main shaft manually using the black knob on the side of the machine. If there is a binding when manually turning, then please find the cause of the mechanical jam. The needle may have bent badly and hit something, or the trimmer knife jammed in the way of the needle. Also, the head may have falling off of needle center for whatever reason and needs to be re-centered per the needle change error. Also check that the three hook screws on the bobbin hook are not loose, and hitting anything. If the shaft feels free and turns all the way, but the motor does not move at all, then one of the three
Event Angle Exception! Motor Over Angle Exception! Motor Over Angle Time Out!	There is a problem reading the main motor encoder. Please verify that the main motor encoder plug is secure, or re-plug it. Also check the main motor encoder cable and make sure the cable shield's metal is not touching the chassis metal of the main motor (remove rubber grommet to inspect). Sometimes the vibration of the machine causes the metal to touch only sometimes.

10 PICTURES

10.1 PICTURES & VIDEOS

High quality pictures and videos can be founds by going to <u>http://www.ButterFlyEmb.com</u> and clicking on either the PHOTOS or VIDEOS tab.



11 PART BOOK

11.1 PARTS BOOK



Butterfly Embroidery Machine

B1501B/T Single Head 15 Needle

Parts Book (Manual Addition)

© Copyright 2020:

TheEmbroideryWarehouse



11.1.1 Frame and Table Components

Parts of the table, chassis and bed. Reference picture on previous page.

٦

1. FRAME AND TABLE COMPONENTS

DIAGRAM/PART	NAME
1/1	MACHINE BRACKET
1/2	MACHINE BRACKET CASE(FRONT RIGHT)
1/3	MACHINE BRACKET CASE(FRONT LEFT)
1/4	MACHINE BRACKET CASE(BACK RIGHT)
1/5	MACHINE BRACKET CASE(BACK LEEFT)
1/6	MACHINE CASE FIXING WASHER
1/7	M4*8 SCREW
1/8	4*6 SCREW
1/9	STRECH FRAME SUPPORT
1/10	SCREW
1/11	TABLE WASHER
1/12	3*20 SCREW
1/13	CIRCLIP
1/14	4*12 SCREW
1/15	TABLE(UPPER)
1/16	TABLE(LOWER)
1/17	MACHINE FRAME
1/18	M10 NUT
1/19	M10 PLAIN WASHER
1/20	M10*100 SCREW
1/21	MACHINE BRACKET SUPPORT
1/22	MACHINE FEET ANTISLIP WASHER
1/23	POWER BOX TABLE
1/24	PLAIN WASHER
1/25	3*20 SCREW
1/26	M12*45 SCREW
1/27	M12 PLAIN WASHER
1/28	M12 NUT
1/29	MACHINE TRADEMARK
1/30	M5*10 SCREW
1/31	WHEEL ASM.
1/32	M8*20 SCREW

1/33 PLAIN WASHER





11.1.2 Rotary Hook Box

Rotary Hook Base. Reference picture on previous page

2. ROTARY HOOK BOX

DIAGRAM/PART	NAME
2/1	MACHINE TABLE
2/2	ROTARY HOOK FRONT CUSHION
2/3	ROTARY HOOK BACK CUSHION
2/4	MAIN MOTOR
2/5	M8*30 SCREW
2/6	M8 SPRING WASHER
2/7	M8 PLAIN WASHER
2/8	MACHINE TABLE BUSHING
2/9	LOWER SHAFT
2/10	BEARING
2/11	BEARING BUSHING
2/12	5M*16ф7.94 LOWER SHAFT PULLEY
2/13	SHAFT CONNECTION
2/14	M5*6 SCREW
2/15	M4*4 SCREW
2/16	M6*8 SCREW
2/17	M6*6 SCREW
2/18	M5*20 SCREW
2/19	ROTARY HOOK BOX COVER
2/20	SCREW
2/21	ROTARY HOOK BOX BIG COVER
2/22	4*8 SCREW
2/23	NEEDLR PLATE(LOWER)
2/24	NEEDLE PLATE(UPPER)
2/25	SCREW
2/26	KNIFE SUPPORT/NEEDLE PLATE BRACKET
2/27	ROTARY HOOK
2/28	ROTARY HOOK CASE
2/29	BOBBIN
2/30	ROTARY HOOK POSITION HOOK
2/31	9/64 SCREW
2/32	3*16 PIN

2/33	SCREW
2/34	ROTARY HOOK BOX GUARD
2/35	4*6 SCREW



3、THREAD CUT COMPONENTS

11.1.3 Thread Cut Components

Reference picture on previous page

3. THREAD CUT PARTS

ſ

DIAGRAM/PART	NAME
3/1	THREAD CUT MOTOR
3/2	THREAD CUT MOTOR BRACKET
3/3	THREAD CUT SENSOR
3/4	M3*8 SCREW
3/5	4*8 SCREW
3/6	RUBBER WASHER
3/7	M4*8 SCREW
3/8	DRIVE ROD
3/9	THREAD CUT SENSOR HEAD
3/10	M4*10 SCREW
3/11	THREAD CUT PITMAN ROD
3/12	PIN
3/13	THREAD CUT DRIVE CONNECTION LEVER
3/14	COPPER BUSHING
3/15	THREAD CUT LEVER
3/16	FLAT EMBROIDERY PITMAN ROD
3/17	DRIVE ROD
3/18	FLEXIBLE KNIFE
3/19	M3*4 SCREW
3/20	SPRING WASHER
3/21	FIXED KNIFE
3/22	M3*3 SCREW
3/23	3*5 SCREW
3/24	POSITION CUSHION
3/25	THREAD PICK PITMAN ROD
3/26	THREAD PICK ELECTROMAGNET ASM.
3/27	THREAD PICK ELECTROMAGNET INSTAL BOARD
3/28	THREAD PICK RESET PLATE

3/29	3.3*3.0 SCREW
3/30	φ3 OPEN CIRCLIP
3/31	2.5*4 SCREW
3/32	PICK FEED BRACKET
3/33	THREAD PICK FORK
3/34	PIN
3/35	PLAIN WASHER
3/36	THREAD PICK FORK BRACKET
3/37	THREAD PICK THRUST BLOCK
3/38	M5*10 SCREW
3/39	M4 PIN
3/40	M4 NUT
3/41	THREAD PICK PIN



11.1.4 Machine Head

Machine Head. Reference picture on previous page

4. MACHINE HEAD

DIAGRAM/PART	NAME
4/1	MACHINE HEAD
4/2	UPPER SHAFT BACK BEARING BUSHING
4/3	BEARING
4/4	M5*6 SCREW
4/5	BEARING
4/6	SENSOR SUPPORT
4/7	4*6 SCREW
4/8	UPPER SHAFT SENSOR
4/9	M4*6 SCREW
4/10	M6*8 SCREW
4/11	M6*6 SCREW
4/12	MACHINE HEAD SHADE WASHER
4/13	WINDING PLATE
4/14	M4*8 SCREW
4/15	M4 SPRING WASHER
4/16	M4 PLAIN WASHER
4/17	HTD5M-15-525 BLET
4/18	UPPER SHAFT PULLEY
4/19	M5*6 SCREW
4/20	6004φ15 BEARING BUSHING
4/21	6004 BEARING
4/22	φ15 UPPER SHAFT
4/23	DIAL
4/24	MACHINE HEAD GUIDE RAIL(9 NEEDLES)
4/24	MACHINE HEAD GUIDE RAIL(12 NEEDLES)
4/25	M4*10 SCREW
4/26	PRESSER FOOT CAM GUARD
4/27	PRESSER FOOT DRIVE CAM
4/28	M8*8 SCREW
4/29	M10*40 SCREW
4/30	M10 SPRING WASHER

4/31	ADJUSTING HANDLE
4/32	M4*4 SCREW
4/33	φ7.94 SHAFT
4/34	SPRING
4/35	ADJUSTING HANDLDE INSTAL BRACKET
4/36	M4*8 SCREW
4/37	GEAR
4/38	SM15/64*28 L=6 SCREW
4/39	THREAD TAKE-UP DRIVE CAM
4/40	SM15/64*28 L=4 SCREW
4/41	CRANKSHAFT
4/42	DOMESTIC CONECTION ROD
4/43	NEEDLE BEARING
4/44	SCREW
4/45	M4*10 SCREW
4/46	LOWER GUIDE RAIL POSITION HOOK
4/47	GUIDE ROD THRUST PLATE
4/48	DUSTPROOF PLATE(LEFT)
4/49	DUSTPROOF PLATE(RIGHT)
4/50	NA4902 NEEDLE BEARING
4/51	GUIDE RAIL SLIDE BLOCK POSITION BRACKET
4/52	SIGHT GLASS
4/53	DIAL FINGER
4/54	M4*6 SCREW
4/55	THRUST PLATE
4/56	THRUST PLATE SUPPORT
4/57	MACHINE HEAD FRONT COVER
4/58	MACHINE HEAD BACK COVER
4/59	THREAD TENSION ASM.
4/60	M4*8 SCREW
4/61	SPOTLIGHT BRACKET
4/62	SPOTLIGHT



5. NEEDLE BAR DRIVE COMPONENTS

٦

11.1.5 Needle Bar Drive Components

Needle Bar Drive Components picture on previous page

5. NEEDLE BAR DRIVE PARTS

DIAGRAM/PART	NAME
5/1	THREAD TAKE-UP DRIVE ROD B
5/2	M4*10 SCREW
5/3	M8 PLAIN WASHER
5/4	THREAD TAKE-UP ROD BEARING BRACKET
5/5	M5 PLAIN WASHER
5/6	M5 SPRING WASHER
5/7	M5*12 SCREW
5/8	THREAD TAKE-UP DRIVE ROD
5/9	CAM DRIVE ROD
5/10	COPPER BUSHING
5/11	DRIVE ROD
5/12	PIN B
5/13	PIN A
5/14	SMALL CONECTION ROD
5/15	M5 NUT
5/16	A DRIVE BEARING BUSHING
5/17	φ10 OUTER CIRCLIP
5/18	DRIVE SHAFT UP-DOWM FLEXIBLE SUPPORT
5/19	3*4 SCREW
5/20	PRESSER FOOT SLIDE BLOCK ASM.
5/21	RUBBER SUPPORT(LARGE)
5/22	DRIVE BEARING BUSHING
5/23	WOOL TOP
5/24	φ7.24 MAIN SHAFT
5/25	SPRING
5/26	689Z BEARING
5/27	WOOL TOP
5/28	M5*6 SCREW
5/29	NEEDLE BAR DRIVE BLOCK ASM.



11.1.6 Upper Thread Holder

Upper Thread Holder. Reference picture on previous page

6. UPPER THREAD HOLDER SETS

DIAGRAM/PART	NAME
6/1	UPPER THREAD MOTOR
6/2	UPPER THREAD MOTOR BASE
6/3	M4*8 SCREW
6/4	M4*6 SCREW
6/5	M4 SPRING WASHER
6/6	M4 PLAIN WASHER
6/7	UPPER THREAD SPRING
6/8	3*6 SCREW
6/9	M3*18 SCREW
6/10	NUT
6/11	CONNECTION ROD
6/12	PIN
6/13	HOOK FIXING BLOCK
6/14	M4*10 SCREW
6/15	UPPER HOOK DRIVE ROD
6/16	M3*10 SCREW
6/17	ERASURE BLOCK
6/18	M5*12 SCREW
6/19	M5 SPRING WASHER
6/20	M5 PLAIN WASHER
6/21	HOOK GUIDE BRACKET
6/22	M3 NUT
6/23	UPPER HOOK SUPPORT
6/24	НООК
6/25	3*4 SCREW
6/26	M5*16 SCREW
6/27	SUPPORT BUSHING
6/28	HOOK GUIDE PLATE
6/29	M4*8 SCREW
6/30	M4*12 SCREW
6/31	JUMPING MOTOR INSTALL BRACKET
6/32	RUBBER WASHER

6/33	M3 PLAIN WASHER
6/34	M3*12 SCREW
6/35	JUMPING CONNECTION ROD SUPPORT
6/36	JUMPING CONNECTION ROD
6/37	4*6 SCREW





11.1.7 Color Change System

Color Change System. Reference picture on previous page

7. COLOR CHANGE PARTS

DIAGRAM/PART	NAME
7/1	COLOR CHANGE MOTOR
7/2	ADJUSTING HANDLE(SMALL)
7/3	M4*6 SCREW
7/4	M4*8 SCREW
7/5	M4 SPRING WASHER
7/6	M4 PLAIN WASHER
7/7	MOTOR SUPPORT
7/8	COLOR CHANGE MOTOR BRACKET
7/9	M5 PLAIN WASHER
7/10	M5 SPRING WASHER
7/11	M5*12 SCREW
7/12	M4*8 SCREW
7/13	696LU(NSK) BEARING
7/14	696LUBEARING
7/15	M3*8 SCREW
7/16	COLOR CHANGE CAM
7/17	M3*5 SCREW
7/18	COLOR CHANGE SUPPORT
7/19	M4 NUT
7/20	POTENTIOMETER SUPPORT
7/21	M4*16 SCREW
7/22	PHOTO COUPLER SUPPORT
7/23	COLOR CHANGE COPPER BUSHING
7/24	COLOR CHANGE BOX CASE
7/25	4*6 SCREW
7/26	POTENTIOMETER



8、NEEDLE BAR BRACKET (1)

11.1.8 Needle Bar Bracket (1)

Needle Bar Bracket (1). Reference picture on previous page

8. NEEDLE BAR BRACKET(1)

DIAGRAM/PART	NAME
8/1	NEEDLE BAR ASM.
8/2	M4*16 SCREW
8/3	DB*K5 75/11 NEEDLE



9、NEEDLE BAR BRACKET (2)

11.1.9 Needle Bar Bracket (2)

Needle Bar Bracket (2). Reference picture on previous page

9. NEEDLE BAR BRACKET(2)

DIAGRAM/PART	NAME
9/1	9 NEEDLES LOWER THREAD GUIDE
9/1	12 NEEDLES LOWER THREAD GUIDE
9/2	9/64 SCREW
9/3	LOWER PLATE(9 NEEDLES)
9/3	LOWER PLATE(12 NEEDLES)
9/4	MEDIAL THREAD GUIDE ASM.(9 NEEDLES)
9/4	MEDIAL THREAD GUIDE ASM.(12 NEEDLES)
9/5	THREAD TENSION ASM.
9/6	9/64 SCREW
9/7	UPPER PLATE(9 NEEDLES)
9/7	UPPER PLATE(12 NEEDLES)
9/8	ON-OFF ANNUNCIATOR SUPPORT
9/9	4*6 SCREW
9/10	CUSHION
9/11	COLOR CHANGE ROLLAR ASM.(9 NEEDLES)
9/11	COLOR CHANGE ROLLAR ASM.(12 NEEDLES)
9/12	M4*12 SCREW
9/13	M4*18 SCREW
9/14	M4 NUT
9/15	GUARD SUPPORT
9/16	M4*8 SCREW
9/17	M4 SPRING WASHER
9/18	M4 PLAIN WASHER
9/19	DUSTPROOF CASE
9/20	MAGNET
9/21	M3*14 SCREW
9/22	M3 NUT





11.1.10 X-Axis Drive Components

X-Axis Drive Components. Reference picture on previous page

10. X-AXIS DRIVE PARTS

DIAGRAM/PART	NAME
10/1	X-AXIS GUIDE RAIL BRACKET
10/2	WOOL TOP
10/3	COVER SUPPORT
10/4	X-AXIS DRIVE COVER
10/5	X-AXIS DRIVE COVER
10/6	4*6 SCREW
10/7	GUIDE RAIL BRACKET RIGHT SUPPORT
10/8	GUIDE RAIL BRACKET LEFT SUPPORT
10/9	M5*12 SCREW
10/10	M5 SPRING WASHER
10/11	M5 PLAIN WASHER
10/12	HK0808 NEEDLE BEARING
10/13	3M*20Ф10 PASSIVE PULLEY
10/14	φ6 OPEN CIRCLIP
10/15	X-AXIS PASSIVE PULLEY BRACKET
10/16	X-AXIS PASSIVE PULLEY BRACKET ADJUSTING FIXING BRACKET
10/17	M4 PLAIN WASHER
10/18	M4*16 SCREW
10/19	M4 SPRING WASHER
10/20	M4*10 SCREW
10/21	M4*8 SCREW
10/22	PIN
10/23	3M*20Ф8 PASSIVE PULLEY
10/24	M5*6 SCREW
10/25	X-AXIS DRIVE MOTOR
10/26	X-AXIS MOTOR COVER
10/27	X-AXIS PHOTO COUPLER BRACKET INSTALL SUPPORT
10/28	X-AXIS STOPPER
10/29	M3*6 SCREW
10/30	750 X-AXIS GUIDE RAIL
10/31	M3*10 SCREW
10/32	DOMESTIC X-AXIS EMBROIDERY FRAME LEFT SUPPORT
-------	--
10/33	DOMESTIC X-AXIS EMBROIDERY FRAME RIGHT SUPPORT
10/34	DRIVE POSITION BLOCK(LEFT)
10/35	DRIVE POSITION BLOCK(RIGHT)
10/36	SPRING PLATE
10/37	M3 PLAIN WASHER
10/38	M3*8 SCREW
10/39	CONNECTION PLATE
10/40	M3 SPRING WASHER
10/41	M3*12 SCREW
10/42	X-AXIS DRIVE BLET PLATE(LOWER)
10/43	M4*12 SCREW
10/44	X-AXIS LIMIT SENSOR
10/45	BLET
10/46	X-AXIS DRIVE BLET PLATE(UPPER)
10/47	RULER





11.1.11 Y-Axis Drive System

Y-Axis Drive System. Reference picture on previous page

11. Y-AXIS DRIVE PARTS

DIAGRAM/PART	NAME
11/1	3m*33ф12 MAIN SHAFT DRIVE WHEEL
11/2	M4*6 SCREW
11/3	Y-AXIS MOTOR BRACKET
11/4	M6*16 SCREW
11/5	86 MOTOR
11/6	M5 SPRING MOTOR
11/7	M5*20 SCREW
11/8	φ12 CONNECTION BUSHION
11/9	M5*6 SCREW
11/10	φ12 Y SHAFT
11/11	BEARING BRACKET
11/12	M5*16 SCREW
11/13	NA4302 NEEDLE BEARING
11/14	BEARING BUSHIONG
11/15	BELT
11/16	Y-AXIS LIMIT SENSOR
11/17	M4 PLAIN WASHER
11/18	M4 SPRING WASHER
11/19	M4*8 SCREW
11/20	M3*12 SCREW
11/21	M3 SPRING WASHER
11/22	M3 PLAIN WASHER
11/23	BLET PLATE
11/24	M4*12 SCREW
11/25	GUIDE RAIL SLIDE BLOCK POSITION BRACKET
11/26	420 STRAIGHT GUIDE RAIL
11/27	M5*12 SCREW
11/28	M5 PLAIN WASHER
11/29	3m*33 PASSIVE PULLEY
11/30	HK0808 NEEDLE BEARING
11/31	φ6 OPEN CIRCLIP
11/32	PIN

11/33	TENSION WHEEL BRACKET
11/34	M5 NUT
11/35	4*6 SCREW
11/36	Y-AXIS STOPPER



12、THREAD TENSION COMPONENTS

11.1.12 Tension Base

Tension Base. Reference picture on previous page

12. THREAD TENSION PARTS

DIAGRAM/PART	NAME
12/1	THREAD GUIDE ASM.(12 NEEDLES)
12/2	M4*16 SCREW
12/3	4*12 SCREW
12/4	INDICATOR
12/5	SENSOR BASEPLATE



13、AUTOMATIC WINDING COMPONENTS

11.1.13 Automatic Winding Components

Automatic Winding Components. Reference picture on previous page

13. AUTOMATIC WINDING PARTS

Г

DIAGRAM/PART	NAME
13/1	WINDING ASM.
13/2	RUBBER WASHER
13/3	BOBBIN
13/4	M4*8 SCREW

٦



14、ELECTRICAL CONTROL COMPONENTS

11.1.14Electrical Control Components

Electrical Control Components. Reference picture on previous page

14. ELECTRICAL CONTROL PARTS

DIAGRAM/PART	NAME
14/1	MACHINE HEAD BACK CASE
14/2	M4*6 SCREW
14/3	M5*10 SCREW
14/4	POWER BASEPLATE ASM.
14/5	4*8 SCREW
14/6	COMPUTER BASEPLATE ASM. A
14/7	COMPUTER BASEPLATE ASM. A
14/8	M4*10 SCREW
14/9	POWER BOX ASM.
14/10	4*25 SCREW



11.1.15 Operating Plate

Operating Plate. Reference picture on previous page

15. OPERATE PLATE

DIAGRAM/PART	NAME
15/1	COMPUTER MONITOR SUPPORT BOARD
15/2	COMPUTER MONITOR CONNECTION BOARD B
15/3	M4*10 SCREW
15/4	M5*10 SCREW
15/5	COMPUTER

٦



11.1.16 Cap Drive Components

Cap Drive Components. Reference picture on previous page

16. CAP DRIVE PARTS

DIAGRAM/PART	NAME
16/1	CAP DRIVE ASM.
16/2	M4*12 SCREW
16/3	M4 PLAIN WASHER
16/4	M5*12 SCREW
16/5	M5 PLAIN WASHER



17、CAP BASE COMPONENTSS

11.1.17 Cap Base Components

Cap Base Components. Reference picture on previous page

17. CAP BASE PARTS

DIAGRAM/PART	NAME
17/1	CAP BASE ASM.

18、CAP FRAME COMPONENTS



89

11.1.18 Cap Frame

Cap Frame. Reference picture on previous page

18. CAP FRAME PARTS

DIAGRAM/PART	NAN	1E
18/1	CAP FRAME ASM.	



11.1.19 Thread Support

Thread Support. Reference picture on previous page

19. THREAD SUPPORT

DIAGRAM/PART	NAME
19/1	THREAD STAND BASEPLATE
19/2	THREAD STAND COLUMN
19/3	NAIL
19/4	M5 PLAIN WASHER
19/5	M5 SPRING WASHER
19/6	M5 NUT
19/7	M4*10 SCREW
19/8	M5*10 SCREW
19/9	M12 PLAIN WASHER
19/10	THREAD TENSION ASM.
19/11	M4 PLAIN WASHER
19/12	BUSHING
19/13	M6*12 SCREW
19/14	THREAD STAND SUPPORT A
19/15	THREAD STAND SUPPORT B
19/16	THREAD STAND SUPPORT C
19/17	THREAD STAND SUPPORT D
19/18	THREAD STAND SUPPORT E
19/19	THREAD STAND SUPPORT F
19/20	PLASTIC TUBE BUSHING
19/21	COPPER TUBE BUSHING
19/22	TUBE

20、EMBROIDERY FRAME



11.1.20 Embroidery Frame

Embroidery Frame. Reference picture on previous page

20. EMBROIDERY FRAME

DIAGRAM/PART	NAME
20/1	X-AXIS FRAME
20/2	Y-AXIS FRAME
20/3	WOOL TOP(SHORT)
20/4	WOOL TOP(LONG)
20/5	FRAME ANGLE IRON
20/6	M6*12 SCREW



Butterfly Embroidery Machine

B1501B/T Single-Head 15 Needle

Control Panel Manual





Contents

Chapter 1 General Information 1
1.1 Warnings and Cautions1
1.2 Main Features
1.3 Technical Specifications6
Chapter 2 Embroidery Guide7
2.1 Structure and Usage Instruction of Control Panel7
2.2 Instruction of the Main Interface
2.3 Basic Procedure of Embroidery15
2.4 Normal Embroidery, Returning and Patching19
2.5 Embroidery Operation20
2.6 Thread-Breakage Detection
2.7 Working Status
Chapter 3 U Disk Management
3.1 Select U Disk22
3.2 Pattern Preview
3.3 Pattern Input25
3.4 Directory Operation
3.5 Create a New Directory in the Current Directory
3.6 Delete Objects from U Disk (including pattern file and directory)27
3.7 Formatting U Disk
Chapter 4 Common Parameters and Color-Changing Order
4.1 Settings of Common Parameters

Contents



4.1.2. Settings of Rotate Angle
4.1.3. Pattern Direction
4.1.4. Prior Mode
4.1.5. Rep. Mode
4.1.6. Rep. Order
4.1.7. X-Y Rep. Times
4.1.8. X-Y Rep. Interval
4.2 Settings of Color-changing Order
4.2.1. Color-changing Interface
4.2.2. Settings of Color-Changing Order
4.2.3. Set Needle Bar Color
Chapter 5 Settings of Embroidery Parameters
5.1 Procedure for Setting General Parameters
5.2 Instruction on Some Functions within General Parameters
5.2.1. Cyclic Embroidery Function
5.2.2. Brake Adjustment (A Must for New Machine)
Chapter 6 Memory Pattern Management
6.1 Memory Pattern Management Interface and Other Memory Pattern
Operation Interfaces
6.2 Select Pattern for Embroidery
6.3 Memory Pattern Preview
6.4 Pattern Output
6.5 Copy the Memory Pattern
6.6 Create Outline Pattern
6.7 Create High-speed Pattern49
-6.8 Divide Pattern www.butterflyemb.com THE EMBROIDERY WAREHOUSE III

Contents
6.9 Create Parameter Pattern
6.10 Mosaic Pattern
6.11 Create Combined Pattern
6.12 Satin Stitch Adjustment55
Chapter 7 Letter Pattern Operation 56
7.1 Enter Main Interface for Letter Embroidery56
7.2 Input Letter String for Embroidery56
7.3 Adjust Letter Pattern
7.4 Save Letter Pattern61
Chapter 8 Assistant Operation
8.1 Frame Selection
8.2 Set Frame Origin64
8.3 Set Offset Point65
8.4 Frame Origin Recovery66
8.5 Clear XY Displacement
8.6 Positioning Idling
8.6.1. Low Speed Idling Forward69
8.6.2. Low Speed Idling Backward69
8.6.3. High Speed Idling Forward69
8.6.4. Go to Next Color70
8.6.5. Forward Idling70
8.6.6. Backward Idling70
Chapter 9 Assistant Operation Function71
9.1 Needle Down
9.2 Wifi NetWord Configuration72

Contents



Chapter 10 Other Functions76
10.1 Statistics
10.2 Machine Debugging78
10.2.1. Touch Screen Correction
10.2.2. Function Configuration
10.3 Language
10.4 Date Set
10.5 Information
Chapter 11 About JF Sequin Embroidery 85
11.1 Brief of Sequin Embroidery85
11.2 Embroidery Procedure of Sequin
11.3 Input Sequin Design
11.4 Edit Sequin Design
11.5 Setting of Multi-Sequin Embroidery Parameters
11.6 Manual Operation of Sequin Embroidery94
11.7 Debugging Multi-Sequin Embroidery94
11.8 Sequin Mending95
Chapter 12 Operation of Zigzag Embroidery
12.1 Functions
12.2 Key Technical Indexes96
12.3 Procedure of Zigzag Embroidery96
12.4 Related Parameter and Setting Mode96
12.5 Relative Operations of Zigzag Embroidery
12.5.1. Shift between Flat Embroidery Position and Zigzag Embroidery Position98
12.5.2. M Axis Operation of Zigzag Embroidery100

Chapter 13 Taping Embroidery 102	2
13.1 Function Introductions102	2
13.2 Main Technical Specification102	2
13.3 Parameters and setting	2
13.4 Relative Operations of Special Embroidery104	4
13.4.1. Shift between Flat Stitch Head and Special Head104)4
13.4.2. M Axis Operation of Special Embroidery10)5
13.4.3. Operations of Clamp Foot)6
13.5 Debugging Special Embroidery100	6
13.6 Steps on Special Embroidery107	7
13.7 Mechanical Category and Driving Mode Selection for Special Embroidery	У
Machines	7
Chapter 14 Online Update of Main Software 109	9
Chapter 15 Update of Software in Peripheral Board 112	2
Appendix 1 Parameter List 116	6
Appendix 2 Directions of U Disk Operation	9
Appendix 3 Automatic Position Limitation Function Instructions fo	or
Apparel Embroidery13	30
Appendix 4 A15 Controller Operation Quick Guide	36

There will be no further notice in case of any change of specifications.



Chapter 1 General Information

Thank you for using Dahao Computerized Control System for Embroidery Machine.

Please read this manual carefully so as to operate the machine correctly and effectively.

Besides that, you should keep this manual properly for future use.

1.1 Warnings and Cautions

In order to avoid fire, electrical shock or unpredicted injuries, you should follow the listed safety rules.

Matters for Attention on Usage				
Danger	r During the operation, do not try to open the machine box. The high voltage contained in some parts is deadly. The rotating parts may cause serious injury.			
ØForbidden	Don't expose the machine to humidity gas, poisonous gas, water, and dust.			
Ø Forbidden	Forbidden Don't store or operate the machine in the vibration area, which may cause trou to the machine.			
Attention	Please abide all the warnings and safety requirements to ensure the security.			
Attention	LCD screen is fragile. Do not use the hard or sharp item to click the screen.			
Attention	ion Please insert U disk correctly and don't force it in, otherwise, USB interface o disk may get damaged			
Attention	We will add appendix if necessary. If there is any difference between the manu and appendix, the content in the appendix shall take precedence.			
	Matters for Attention on Transportation and Loading			
Attention	When moving the machine, please not to hold the cable.			
Attention	Attention Please abide all the warnings and safety requirements to ensure the security.			
Compulsory Overloading may cause serious loss. Please load according to the instruction of the box				



Matters for Attention on Installation				
Attention	Don't jam the vent on the device. Don't insert other items into the machine, or it may get fire.			
Attention	Make sure the installation direction is correct.			
Attention	Don't expose the machine to humidity gas, corrosive gas, water, and other flammable material.			
	Matters for Attention on Cable Connection			
ØForbidden	Don't test the insulation of the circuit loop.			
ØForbidden	Never try to connect the overloaded electronic device on the connectors (like sockets or terminals).			
Attention	The insulation condition of each cable (no matter signal cable or power cable) should be ensured.			
Attention	The signal cables and power cables should be separated. Never tie them together.			
Attention	All the cables should be well fixed. Don't put any strength on cables. Make sure each turning point of cable is well protected. Add shelter pipes to increase insulating capability if necessary.			
Attention	must be grounded. The equipment-grounding conductor should use the wire with insulation having an outer surface that is green, with or without yellow stripes. the cross-sectional area of the wire shall not be less than 2mm^2 , and the grounding resistance should be less than 10Ω . The equipment-grounding conductor must be pressed crimping to the circular pre-insulated terminal and connected to the position where the grounding mark of the machine case is.			
	Matters for Attention on Operation			
Danger	Don't operate the machine when there is any damage on the shelter of the running parts.			
ØForbidden	When machine is running, do not touch any running part.			
Attention	Attention Make sure the configuration of power supply is in normal. Use stabilized voltage power supply when the change of voltage is beyond the range of -10%~10%.			
<u>Attention</u> In case of warning, please check out the problem. Operation can only be car out again when problem is solved.				



Attention	The power supply switch has over-current protection function. If the over-current switch is activated, the switch can only be closed after 3 minutes.			
Matters for Attention on Maintenance and Inspection				
Warning	If you need to open the machine cover, please cut off the power supply at first. Due to the capacitance, operator must wait at least one minute before opening the machine cover.			
Attention	Circuit boards can be damaged by static. The circuit boards can only be disassembled by professional technicians.			
Attention	If machine is inactive for a while temporarily, users must power on the machine regularly (once by every 2 or 3 days, more than an hour for each time).			
Attention	Attention If machine is inactive for a long time, users should have the machine checked before power-on.			
Matters for Attention on Rejection				
Attention	Rejection should obey the rules and regulations set by national industrial electronic standards.			

1.2 Main Features

1. User-friendly Interface on Touching Panel

The adoption of the touching panel technology offers user the delightful operation and easy learning. The beautiful screen display turns everyday work into joyful experiences.

2. Huge Memory Capacity

The memory capacity reaches 100 million stitches, which can meet demands of different customers.

3. Maximum Stitch Amount of One Pattern Reaches Two Million

At present a single pattern in the system has the maximum of 2 million stitches and 1,000 times of automatic color changing.

4. Multi-Task Parallel Operation and Free Shift among Tasks

During the embroidery, actions like pattern input & output, preparation for the following patterns and modification of parameters can be carried out.



5. Storage of Frequently Used Parameters and Color-Changing Order for Each Pattern

Pattern will be saved along with its parameters, color-changing orders and needle bar colors. System can save the operational details for each pattern. Users can set parameters for a pattern during the embroidery process of the previous pattern, which will save time and improve efficiency. Moreover, it is one basis to realize network management.

6. Pattern Input/Output via USB

Customers can use USB disk for data transfer. USB disk supports DIR operation, which is easy for pattern management. For each directory, system supports operation of 400 patterns or sub-directory. There is no limitation of directory levels. Patterns in the formats of Binary, Ternary and Z-nary can be loaded.

7. Patch Embroidery

This function can set a patch point at the position of color code or stop code, and when the machine embroiders to the patch point, it will halt and move out frame for patching. After sticking a patch, user would press the start key to return the frame and continue embroidering.

8. Brake Adjustment

User can adjust the parameter of brake to let the main shaft stop at the correct position according to the characters of his own machines.

9. Save Start Point

This function can save the start point of each pattern, which saves the work of user to search the start point manually at embroidering the identical pattern.

10. Mechanical Maintainence and Debugging

This function is to easily judge the malfunctions at maintaining and debugging the machine, such as encoder testing, main shaft speed testing, machine parts testing and the main shaft stopping at any position, etc.

11. Multi-Language Support

Currently, the system supports the display in Chinese, English, Spanish and Turkish, Russian, French and many other languages.



12. Pattern Output

Patterns can be output and saved into USB disk. Adoption of TAJIMA's binary format enjoys the advantage of data transmitting through the World Wide Web (other formats may not be transmitted directly).

13. Repetition Embroidery

The user can increase embroidery productivity by using the function of repetition embroidery, which can also be used with cyclic embroidery.

14. Cyclic Embroidery

With this function, the machine can automatically return to the origin and start the same embroidery again when finishing the pattern one time. User also can increase productivity rapidly by combining this function with special pattern-making function or repetition embroidery function.

15. Pattern Compiling

(1) Compiling the Data of Selected Pattern to Generate New Pattern

Users can compile any pattern according to zoom ratio, rotate angle, normal repetition or partial repetition to generate a new pattern and save it to memory. The newly generated pattern can be used for embroidering, output or other operations.

(2) Compiling the Combined Pattern

After setting the combined pattern, the system can compile that pattern to generate a new one and save it to memory. The newly generated pattern can be used for embroidering, output or other operations.

16. Letter Pattern

There are 28 built-in font libraries. Users can make letter groups and change letter orders according to different tasks. This operation is vivid, simple and easy managing.

17. Pattern Edit (under developing)

18. Speed Adjustment

The highest speed for embroidery can be preset. During embroidery, speed may change automatically along with the change of needle interval.



19. Thread-trimming

Thread-trimming can be manually operated. The machine can trim the thread automatically at the end of embroidery process or at color-changing.

20. Thread-breakage Detection

In case of thread breakage or running-out of bobbin thread, the machine will stop and give warning by indicator.

21. Color-changing

At the color-changing point, user can either perform the color-changing manually or let the system do it automatically according to the preset order.

1.3 Technical Specifications

- 1. Maximum number of patterns saved in memory: 800
- 2. Memory capacity: 100 million stitches
- 3. Screen resolution ratio: 1280*800
- 4. Network port speed: 100Mbps
- 5. Supported method for data exchange: USB disk, network
- 6. Control precision: Minimum controllable stitch interval is 0.1mm
- 7. Stitch range: 0.1mm~12.7mm



Chapter 2 Embroidery Guide

2.1 Structure and Usage Instruction of Control Panel

I. Structure of Control Panel



1. Touching Panel

It adopts high-luminance LCD displayer and touching screen man-machine interaction interface.

2. Buttons

Press the keys to start the embroidery, pause the embroidery.

3. Main USB Port

USB disk can be plugged for data input/output.

II. Instructions on Touching Panel

This machine uses the touching panel as its input device. In order to extend the service life of the panel and to maintain its performance, please don't apply too much pressure on the screen during operation. Neither can user use the sharp or hard tools to click the screen.

III. Instructions on USB Disk

Please pay close attention to electrostatic phenomenon. Don't forget to discharge (we suggest you should touch the machine stand or frame to discharge the static) before plugging in/out the USB disk.

Pay attention to the direction of the USB disk at plug-in. Don't pull out the USB disk when system loads data from or write data to it. If the USB disk is pulled out or the power is



cut off during the data input/output, the data could be lost. In that case, please check the integrity of data in the USB disk and repair it before using.

Attention: During the process of initialization, if the power is cut off or the USB disk is pulled out, the USB disk may be damaged permanently.

2.2 Instruction of the Main Interface



No.	Icon	Name	Description	Reference Page
		Network Connection Failure Status	Network Status (disconnected , connected , successful registration	
	(h?	Wifi Connection Status	Wifi Connection Status (disconnected $\mathbf{\hat{s}}$, connected $\mathbf{\hat{s}}$)	
	١	Cyclic Embroidery	Cyclic embroidery is currently available. Press user parameter or specialist parameter to enter the parameter setting interface, where user can change the setting of cyclic embroidery.	


No	Icon	Name	Description	Reference
110.	icon	Traine	Description	Page
	(F ×	Thread Breakage	This figure will appear when the machine stops due to the thread-breakage.	
1	1	Frame Number Display	Frame in use	
	¢	High-speed Manual Frame-moving Status	When the machine stops, press the manual frame-moving keys to move the frame, and the frame will move in the high speed. Switch between and can be activated by the switching key on the panel.	
	%	Low-speed Manual Frame-moving Status	Different from the High-speed Manual Frame-moving Status, it is used for manual adjustment of the frame position.	
		Pattern Management	Interface for pattern management	
2	\$ 2	Parameter Setting	Interface for parameter setting	
Ζ		Color-changing Order Setting	Interface for color-changing order setting	
		Main Interface	Main interface	
3		Pattern Display Area	The pattern for embroidery will be displayed in this area.	
4		Basic Pattern Data	Basic data of the current pattern will be displayed here.	
4	Clear X/Y Displacement		Clear the current value of X/Y displacement	
E	Manual Thread-trimming		After machine stop, user can click this key for the operation of manual thread-trimming (including bobbin thread trimming).	Section 2.3
5		Main Shaft Manual Adjustment	After stop, if the main shaft is not at the proper position \bigotimes , press this key to adjust the main	Section 2.3



No.	Icon	Name	Description	Reference
			1	Page
			shaft to the right position 🔫	
		Frame Selection and Position	Frame selection and position	
		Auto Color-changing, Auto Start	If the machine is set at Auto Color- changing, user should set the color-	
		Auto Color-changing Manual Start	changing order in advance. When user presses the start key for embroidery, no matter where the current needle rod locates, the machine will change the needle according to the set color-changing order and perform the embroidery. When encountering color-changing code, the machine will stop automatically and shift to the pointed needle position according to the auto color-changing order. If the machine is set at auto start, the machine will begin the embroidery automatically; if it is set at manual start, the user needs to press the start key for embroidery.	
5		Manual Color-changing, Manual Start	In this status, select the needle position with manual color-changing ()) to select the needle position and then press start key for embroiery. When encountering color-changing code, the machine will stop automatically. Icon i appears, and the system awaits the manual color-changing At this moment, user needs to perform manual color-changing ()) to shift to the needed needle position, and press the start key for embroidery	
	(+)	Main Shaft Acceleration, Main Shaft Deceleration	For setting the main shaft acceleration/deceleration. When	



No	Icon	Name	Description	Reference
110.	icon	Traine	Description	Page
			the main shaft reaches the highest/lowest speed, this key will be unavailable.	
	0+/-	Idling	Used to move the frame to appointed position without embroidery	
	0→0	Back to Origin	After the machine stops, user can click this key to have the frame automatically return to the origin of the current design.	
		Back to Stop Point	After the machine stops, user can click Manual Frame-moving key to move the frame (like appliqué). Then user can click this key to have the frame return to the stop point of current design.	
	61	Embroidery Ready Status, Confirm the Embroidery	When the machine is in Ready Status, user can carry out preparation work of the embroidery, such as pattern selection, setting scale parameter, setting repetition parameters and so on. Click this key to confirm, and the machine will turn from Embroidery Ready Status into Embroidery Confirmation Status	
6		Embroidery Confirmation Status, Cancel the Embroidery	Currently, the machine is under Embroidery Confirmation Status, and user can start embroidery at any time. When the machine stops, user can click this key and confirm the cancelling of Embroidery Confirmation Status. And the machine will return to Embroidery Ready Status of from Embroidery Confirmation Status	
6	-	Other Function Operations	Press it to enter the interface for other function operations, such as statistic inquiry, frame origin	Chapter 9



No Icon		Nomo	Description	Reference
INO.	ICOII	Iname	Description	Page
			setting, power-off recovery, soft limitation setting, machine authority management, touch screen calibration, and time management.	
	™	Assistant embroidery operation	needle stops down, sequin, special embroidery, etc.	
6		Manual Color-changing	When machine stops at correct position , the operation is valid; press it to enter manual color-changing interface, where user can click corresponding needle position number to make color-changing.	Section 2.3
	01	Current Needle Position	This figure is for the actual needle position at present. 0 is for the invalid needle position.	
7		Current Color-changing Times	The initial value is 1. After the embroidery starts, this value will add 1 at each finish of successful color-changing.	
7	Color-changing Order		This order is the sequence of the needle rods for changing color. The 3D figure is for the current needle position.	
	()	Scale Up Pattern	Scale up pattern in the pattern display area. Hold pressing for 2s to shift to .	
8		Manual Frame-moving	The frame will move along with the direction keys.	





No.	Icon	Name	Description	Reference Page
9		Pattern List	Display patterns by figures for users to select	
10		Pattern Sort	Pattern arrangement: Sort by pattern number , Sort by time	
		Previous/Next Page	Display patterns in different pages	
	S'	Memory Pattern Preview	Used to check pattern details, scale up/down pattern, move or make analog display of pattern	
		Letter Pattern	Letter pattern and its parameter setting	
	Pattern Deletion		Used to delete selected patterns	
11		Pattern Output	Used to transfer memory patterns to USB disk	
11	U Disk Management	Press it to enter the U disk management interface for operations related to U disk.		
	Other Functions		Used to open other operation interfaces for memory patterns, such as pattern copy, deletion, combination, edit, etc.	
		Single/Multiple Selection	Shift between single selection mode and multiple selection mode	





No.	Icon	Name	Description	Reference Page
12		Common Parameter Setting	User can adjust these parameters to control the final embroidery effect of the pattern.	
12		Pattern Preview	Load the selected pattern, display the pattern data and draw up the pattern shape.	





No.	Icon	Name	Description	Reference Page
	4 4 🗞	Current Operation Position	Set, insert or delete needle bar number here.	
	1	Color Lump Number List	Display the color lump number of the pattern	
	1	Needle Bar Number and Color	Display the needle bar number and needle bar thread color of the corresponding color lump	
		Move Up	Move up the color-changing list in order to select the color lump to be set	
13	, , , e	Insert Needle Bar Number	Press this key and then press needle bar number to insert it to the current needle bar number list	
	Delete Needle Bar Number		Delete the current needle bar number from the needle bar number list	
		Move Down	Move down the color-changing list in order to select the color lump to be set	
	1 2 3 4 5 6 7 8 9 0 11 0 3 14 15	NeedleBarNumberColorSelection Area	Select the color for the selected needle bar number	
		Repetition	Repeat the color-changing order	
14		Patch Embroidery	Set as patch embroidery pattern	
		Needle Bar Color Setting	Set the neeble bar color from default colors	

2.3 Basic Procedure of Embroidery

The machine carries out embroidery based on the patterns saved in memory. The following figure is the basic procedure of the embroidery:





I. Input Patterns

User can input patternss through network or USB disk. Only with $\Box \checkmark$ (successful registration) displayed, can it be possible to transmit patternss by network. For U disk operation, in pattern management interface, press to enter U disk management interface.

II. Select Pattern

In pattern management interface, user can select needed pattern for embroidery.

III. Assistant Operations

After selecting the pattern for embroidery, user can make assistant operations according to need before embroidery.

1. Set repetition, rotation and scaling — press > 10 enter parameter management interface.

2. Set color-changing orde — press to enter color-changing setting interface.

3. Set patch embroidery — press / which are color-changing setting



interface and set patch embroidery of the pattern according to hints.

4. For border inquiry, border idling, pattern outline — press to enter frame selection and position operation.

5. Locate pattern at frame center — press to enter frame selection and position operation. Please note this function is to locate pattern at the frame center set by soft limitation.

6. Set cyclic embroidery — press to enter other function operation.

Press to enter parameter management interface. Then press "Embroidery Assistant Parameters" and set cyclic embroidery according to hints.

IV. Confirm Embroidery

1. After assistant operations, press **b** to display a hint window, where user can

select violation select violation in the select violation of the select violat

(confirm embroidery), which indicates the machine has entered Embroidery Ready Status.

If user selects , the machine will stay at Embroidery Cancel Status. At this time, the machine will not work even when user presses the start key. A hint window will display on the screen for user to confirm the embroidery.

2. Set Color-changing and Start Mode

Switch among (Auto Color-changing, Auto Start), (Auto Color-changing, Manual Start) and (Manual Color-changing, Manual Start)

V. Manual Operation

1. Manual Thread-trimming:

When the machine stops, press in the main interface to display a hint window, where user can press "Trim Upper&Bobbin Thread" to trim threads, or click "Trim Bobbin Thread" to trim the bobbin thread only. Press of quit the thread-trimming operation.





2. Manual Frame-Moving:

When the machine stops, press direction keys (, , , , , , ,) to move frame along the corresponding direction. Press the two neighboring keys at the same time to move the frame in the direction of the angle bisector. () is the speed key for manual frame-moving. Press to shift between () (high speed) and () (low speed).

3. Clear the Frame Coordinates

When the machine stops, press **C** to clear the XY displacements displayed in the main interface. The function can be used with manual frame-moving.

4. Manual Color-Changing

When the machine stops, press in the main interface to enter manual color-changing interface. Then click the needle number for color-changing, and the machine head will automatically move to the corresponding needle position.

Please note: if the user wants to automatically save the order of the manual color-changing, user should operate it in the manual color-changing interface on the touch screen.

5. Adjust Main Shaft Manually

Usually, the main shaft needs to stop at 100° at needle/color-changing, framemoving and beginning embroidery. User can manually turn the main shaft to

100° when it hasn't reached there. Press in the main interface to carry out this function.



After the operation, 🔌 (not in position) will changing into 🥶 (in position).

6. Back to Origin

Press $\mathbf{v}_{\rightarrow \mathbf{v}}$ to return the frame to origin.

7. Back to Stop Point

Press to return the frame to stop point.

8. Positioned Idling

Use this function after embroidery confirmation. Positioned idling enables the

machine to move to the appointed position without embroidering according to the

user's requests. Press to set the needle number, color-changing code and stop code for performing the positioned idling forward or backward.

VI. Cancel Embroidery

When	the mach	ine stops,	press	U 🕽	to dis	splay a	hint	windo	w, where	user can
select		to turn	U 1	(embi	roidery	confir	matio	on) to	61	(cancel
embroi	idery con	firmation).								
		Question								
		Make su	ure cance	l Confirm	?					

2.4 Normal Embroidery, Returning and Patching

In embroidery confirmation status (is displayed), press (to start normal
embroidery, and during embroidery, press O to stop embroidery.
When the machine stops, press c to return the frame back along with the original
embroidery path; one press, one stitch back; hold pressing for 2s to return continuously, even

www.butterflyemb.com THE EMBROIDERY WAREHOUSE



without holding ; press again to stop.

The purpose of returning is for patching, and when the machine stops returning, press to start normal embroidery.

2.5 Embroidery Operation

When the machine stops, press to start embroidery; When the machine is embroidering, press to stop embroidery.

2.6 Thread-Breakage Detection

Based on different working principles, thread-breakage detection devices have three types: thread take-up spring type, thread winding wheel (chopper wheel) type and mixed type.

For thread take-up spring type, it detects the thread-breakage by searching connection of take-up spring and contact point. When thread breaks, the spring will close to the contact point. In normal condition, this detecting type is sensitive to the face thread breakage, but can hardly detect bobbin thread run-out. In case you change the embroidery thread, or thread tension changes, you need to adjust spring pressure between the take-up spring and contact point. When the spring pressure is too large, there will be False Alarm; when the spring pressure is too small, there will be Missing Alarm.

For thread winding wheel type, it judges thread-breakage by detecting the winding wheel angle. It is very sensitive in case of face thread breakage; in most cases of bobbin thread runout, the consumption of face thread will reduce, as a result, system will judge by statistic method and send out warning. Though it can almost avoid False Positive, it is not as sensitive as the spring-type.

For the mixed type method, the two can complement each other with their advantages, which results in sensitive and stabilized detecting effect.

2.7 Working Status

There are three working statuses:



- 1. Embroidery Ready Status preset parameters, choose embroidery patterns and make other preparation work for embroidery.
- Embroidery Confirmation status
 enter the quasi-running status.

3. Embroidery Running Status ——embroidery. Shift among these three working statuses:

In embroidery ready status (is displayed in the main interface), if users have

selected pattern and related parameters, press **N** and then press **v** to confirm,

and the system will enter embroidery confirmation status (is displayed in the main

interface). At this time, press start key to start embroidery, when the machine is under

embroidery running status (is displayed in the main interface).

In embroidery running status (is displayed in the main interface), press stop key to

stop embroidery and return to embroidery confirmation status, where user can press start key again to enter embroidery running status.

In embroidery confirmation status (is displayed in the main interface), press



and then press

to confirm, user can release the confirmation status and

return to embroidery ready status (

is displayed in the main interface).

Chapter 3 U Disk Management

In U disk management interface, user can input patternss from U disk to machine, and vise versa; meanwhile, user can undertake some common U disk managements, like erasing file or directory, initializing the disk, etc. User can save patterns data under different directories of the U disk based on different types. Patterns formats like DSB, DST and DSZ can be read by the system. For data output, patterns will be saved in the U disk as DSB format.

3.1 Select U Disk

Since the system supports several storage devices, user need select the U disk for operation.

1. Press in pattern management interface.

2. System will display "Select U Disk" window, where user need select U disk by pressing corresponding icon.

Select UDisk		
USB 1	USB 2	
	P	

In this window all the storage devices will be displayed. Their information includes the icon, words and numbers. The icon is the device type. Icon **error** indicates U disk. The words are the label of the U disk (if the U disk has no label, the default letter will be used), and the number refers to the U disk's digital symbol.



3. Enter U disk operation interface.



No.	Icon	Name	Description		
1		File List	Display the pattern files and file folders within the U disk in icons. It's used to select files.		
2	Page Information		The current page number and total page number		
2		Back to Upper Level	Return to upper level		
3		Basic Pattern Data	Display the basic data of current pattern		
	E	Pattern Preview	Load the selected pattern. Check its details, scale up/down the pattern, and move or make analog display of the pattern.		
	+	Create Directory	Create new file folder		
		Deletion	Delete the file or file folder		
4	-	Formatting U Disk	Formatting the U disk		
	*	Pattern Input	Import the patterns in the U disk to memory.		
		Single/Multiple Selection	Shift between single selection mode and multiple selection mode		
		Exit	Exit U disk management.		



3.2 Pattern Preview

1. In the U disk management interface, press the pattern for preview.



Pattern files and directories are shown in figure in the list. One page of the list contains 8 items. If the amount of the object within the current directory is more than 8, the object list will be displayed in many pages. Click the key to turn page and look for patternss in another page. The selected object has a different frame and background color.

2. Press





The system loads the data from the U disk and user can check details of the pattern, scaleup/down the pattern, move or make analog display of the pattern. For more information, please refer to section 6.3.

3.3 Pattern Input

To input patterns within the U disk to the machine's memory, user need select the pattern files to be inputted, and then input the number and name for the patterns to be saved in memory.

- 1. Select pattern files of the U disk;
- 2. Press and the system will require input of pattern number and name;



3. Input the pattern number and name to be saved in memory;

lm	port Patter	'n	-				
	Pattern N	um	55				
	Pattern Na	ame	WU	JIAOXING			
	1 abc	de	2 ef	3 ghi			
	4 jkl	m	5 no	6 pqr	C		
	7 stu vv		S v x	9 yz			
	A ∽a	()				



The system provides the minimum available pattern number as the default value. User can use the keypad below to change the number.

- 4. Press v to confirm;
- 5. The system will save the pattern data from the U disk to the memory.

3.4 Directory Operation

1. Enter directory:

Double click the icon of the object directory to enter it, and the system will load the item list of the directory and refresh the display interface.

- 2. Return to Upper Level:
- Press

to return to the upper level of directory and refresh the display interface.

3.5 Create a New Directory in the Current Directory

- 1. Press
- 2. Input the new directory name

ile Nam	ne Ne	w	
1	2	3	×
abc	def	ghi	
4	5	6	C
jkl	mno	pqr	
7	8	9	•
stu	vwx	y z	
A	0		/

3. Press

System will create the corresponding directory in the U disk and refresh the current object list.



3.6 Delete Objects from U Disk (including pattern file and directory)

- 1. Select objects to be deleted;
- 2. Press to delete;



3. System will ask user to confirm the deletion.



Note:

If the user wants to delete a directory, the system will delete all the files and subdirectories within this directory. In case of "Read Only" or "U Disk Write Protection", the file will be unable to delete.



3.7 Formatting U Disk

1. Select the U disk for formatting;

2.	Press		to start formatting;
		VVa	Irnning
		Do	you want to format the udisk?
3.	Press		to confirm

System will begin to format the disk and return automatically to U disk management interface after finishing formatting.

Note: system will format the U disk according to DOS format.



Chapter 4 Common Parameters and Color-Changing Order

In this system each pattern has its own settings of the normal parameters (like scale and repetition) and color-changing order. When a new pattern is selected, the corresponding settings of normal parameters and color-changing order will become effective.

In this chapter, we will discuss the setting of the most frequently used parameters and color-changing order, in parameter setting interface (

Since this system supports multi-task operation, user can set and modify the normal parameters and color-changing order of the patternss that are not embroidered at present. User can enter these operations via other operation interface under pattern management (see Chapter 6).

4.1 Settings of Common Parameters

These common parameters include: "Direction", "Angle", "Scale X/Y", "Prior Mode", "Rep. Mode", "Rep. Order", "Rep. Times", and "Rep. Interval". User can control the final embroidery results by adjusting these parameters.

Press to enter parameter setting interface:





The way for setting the parameter is similar to each other. This chapter will explain how to set the "X/Y Scale" as an example and give the definitions of other parameters (refer to 4.1.1 for setting method).

4.1.1. Settings of X-Y Scale

This parameter controls the scaling percentages on X (horizontal) and Y (vertical) direction, so as to scale up/down the patterns.



1. Press the function item of "Scale X/Y"





System will display independently the modification windows for X Scale and Y Scale for users to set respectively.

2. Adjusting X-Y Scales

User can press number pad to modify the scaling rate at X direction, press

С



cancel the last input digit and press

to clear the input number.

	2	3	
abc	def	ghi	
4 jkl	5 mno	6 pqr	C
7 stu	8 vwx	9 y z	
+/-	0		/

The modification method of Y Scale is the same with that of X Scale.

4.1.2. Settings of Rotate Angle

Press

3.

User can rotate patterns to a certain angle by this parameter.





4.1.3. Pattern Direction

图案方向	р	p	d	σ	q	σ	b	þ	р
刺绣结果	F	ш	Е	П	F	г	F	Е	F

4.1.4. Prior Mode

There are two modes: "rotation prior to scaling" and "scaling prior to rotation". When user has set the parameters "Scale X/Y" and "Rotate Angle", the patterns will rotate first and then scale up/down, if "rotation prior to scaling" mode is selected. Otherwise it will scale up/down first and then rotate.

4.1.5. Rep. Mode

There are two repetition modes: normal and partial.

4.1.6. Rep. Order

There are two modes: X first and Y first.





X repetition times represent the number of columns, while Y repetition times the number of lines; as shown in the above picture, X repetition times are 3 and Y repetition times is 2. The largest set value is 99*99.

4.1.8. X-Y Rep. Interval

The above picture has explained the meaning.

4.2 Settings of Color-changing Order

4.2.1. Color-changing Interface



No.	Icon	Name	Description
1		Pattern Display Area	Display the pattern according to real- time setting of color-changing order, for the preview of the result of color-changing.
2		Basic Pattern Data	Display the basic data of the pattern
3	4 4 🐼	Current Operation Position	User can set, insert or delete needle bar number in current position.
3	1	Color Lump Number	Display the number of the color lumps



No.	Icon	Name	Description
		List	of the pattern
	1	Needle Bar Number and Color	Display the needle bar number and thread color of each corresponding color lump
		Move Up	Move upward the color-changing list to select the color lump for setting
	P	Insert Needle Bar Number	Click this key and a needle number to insert it in the current list of needle list.
		Delete Needle Bar Number	Delete the needle number of the current operation position in the needle list.
		Move Down	Move downward the color-changing list to select the color lump for setting
4		Color Selection Area	Select the color for the needle bar number to be set
	ÎM	Repetition	Repeat color-changing order
5		Patch Embroidery	Set the patch embroidery of the pattern
	Q	Pattern Preview	Load the selected pattern, check the pattern data and create the pattern icon
		Set Needle Bar Color	Select default colors to set the color of each needle bar

The pattern display area displays the pattern under color-changing setting. After changing the color-changing order, the display will be renewed at same time to show the modification effect.

Color-changing order display area shows color lump numbers, needle bar numbers and needle bar colors.

Pattern display can be in parallel with the setting, insertion and deletion of needle bar number, which means that users can set and change the color-changing order along with the display.

4.2.2. Settings of Color-Changing Order

1. Press to enter color-changing setting interface.

2. Input the needle bar numbers in order in the needle bar number selection area. The pattern display and the color list will be refreshed after each input.

to check whether the inputted color-changing order is 3. Press correct. Or press 1 to "Color Index" interface, input the color block number you want to view, and then press to jump to the color block.



4. To change a certain needle bar number, press to move to the item to be modified and then press the new needle bar number.

To insert a new needle bar number, press 5.

to move to the

positon below the position to be inserted, and then **1** to insert the needle bar number.

to delete a needle bar number. Press 6.

4.2.3. Set Needle Bar Color

To make the display effect close to the actual embroidery effect, this system allows settings of color for each needle bar and such settings can be saved together with the colorchanging order of the pattern.

- to enter color-changing setting interface. 1. Press
- to enter needle bar color setting interface. 2. Press







45 default colors for selection in the setting interface

3. To set the needle bar color, select the needle bar first and then select the color from the 45 default color lumps. The corresponding color of the needle bar button will be refreshed.

4. Press v to save the settings and return to the color-changing order setting interface; or press v to quit setting without saving and return to color-changing order setting interface.

Chapter 5 Settings of Embroidery Parameters

Parameters are grouped according to different functions (see Appendix 1 Parameter List)

in the main interface and press

ress 🔍

(for user) or

(for

specialist) to enter parameter setting interface.

Press



1. After system enters parameter setting interface, user can select the parameter for setting.

o ♥× 第	D 10:25	AHAO 5 2016-04-12
- 🖕 💛		
1 Needles D01 <1, 15>	15	
2 Machine IP C43	0. 0. 0. 0	
3 Subnetmask C45	0. 0. 0. 0	
Gateway C46	0. 0. 0. 0	
5 Number of heads D68 <1,10>	1	
6 Machine head distance E45 <1,1500>	330	
1		
8		
9		
10		
Mach	1/1 🕨	



Note:

- the number, name and current value of each parameter are displayed in the parameter list window.
- Enter parameter management interface, press category selection 📃 to check related parameters quickly.



5.1 Procedure for Setting General Parameters

The setting procedure is similar for each general parameter. You can follow the guide of this section to set all parameters.

1. Select Parameter Type

User can use the keys at the bottom of the screen (parameter type key and page key) to

look for the parameter.

If you want to modify the number of needles whose parameter number is D01, press

to find machine configuration parameter and the its parameter list will be displayed.



💀 🕄 🚿 채 2 😻 D	AHAO 2020-06-03
🔺 👌 🖕 🗡 📥	
(1) Needle Number 15 D01 <1,15>	
2 openLoop stepper change color curve curve 0 K2 <0,7>	
(3) Machine IP 192.168.7.100	
4 Subnetmask 255.255.255.0	
5 Gateway 192.168.7.254	
6 DNS Server 0.0.0.0	
7 Start DHCP no	ON OFF
8 X Coarse and Fine Adjustment C49 <0,1>	
9 Y Coarse and Fine Adjustment C50 <0,1>	
10 Test DIP1 0 E1 <0,255>	
Mac. Config. > < 1/3	

2. Press the parameter to be set and input the new value by the number keys.

1	2	3
abc	def	ghi
4	5	6
jkl	mno	pqr
7	8	9
stu	vwx	yz
+/-	0	

3.

Press

to finish the setting.

5.2 Instruction on Some Functions within General Parameters

There are brief descriptions of parameters in the appendix 1. Here, we will introduce some functions mainly used in embroidery.

5.2.1. Cyclic Embroidery Function

This function is to increase the embroidery productivity.

When the parameter "To Do Cyclic Emb." is set as "Yes", the cyclic embroidery function is activated and the icon (i) will appear in the main interface. If this function is activated, the machine will automatically embroider the patterns again without



any operation when completing it.

Usually, cyclic embroidery should accompany repetition embroidery and specially made patterns, and the parameter "Auto Origin" should be also set as "Yes". Thus when the machine is embroidering the back fabric, the front one can be replaced. After embroidering the patternsated patterns, the frame will automatically return to the start point and the machine will automatically embroider the front fabric again and at this time it's possible for user to replace the back one.

5.2.2. Brake Adjustment (A Must for New Machine)

This function is to adjust the control parameters for braking, so as to fit machines with different mechanical characters, which is also able to change with the machine running. Thus this function can help the machinery parts to work better with the computer. The function depends on the parameters "Set Brake Para".

"Set Brake Para" is to adjust the stop position of the main shaft. When the main shaft often stops at the position below 100 degree, the user can increase the parameter value. When the main shaft often stops at the position over 100 degree, the user can decrease the parameter value. Thus the user can adjust the value to let the main shaft stop close to 100 degree. The value can be set between 0 and 30.

After adjusting this parameter, the user can click the task swift key on the panel to return

to the main interface. Click and to make the adjustment and check the effects of the parameter adjustment. If the user is not satisfied with the effects, he can press the swift key on the panel to return to the parameter setting interface, where he can adjust the parameter setting again. Close the parameter setting interface in the end.



Chapter 6 Memory Pattern Management

Memory pattern management includes selection of embroidery patterns, settings of patterns, change of patterns and operations for creating patterns.

6.1 Memory Pattern Management Interface and Other Memory Pattern Operation Interfaces

Press to enter memory pattern management interface.

The memory patterns management interface contains: patterns image display area, navigation and pagination area, information area and management operation area. The patterns image display area can show 8 patternss at most. If the total number of the patterns is beyond 8, more pages will be needed. Navigation and pagination area can help switch to the patternsated page. The management operation area is to preview patternss and set their order.



No.	Icon	Name	Description
1		Pattern Display Area	Display the pattern files in memory by icons. It's mainly for selection.



No.	Icon	Name	Description
2		Pattern sort	Pattern arrangement: Sort by pattern number
2		Previous/Next Page	Used to shift to appointed page number
3		Information Area	Display the detailed information of the selected pattern and the memory information.
	N	Pattern Preview	Check the details of the pattern; scale up/down, move or simulate the pattern.
		Letter Pattern	Set letter embroidery and its parameters
		Delete Pattern	Delete the selected pattern
4		Pattern Output	Save the memory pattern to U disk
		U Disk Management	Press it to enter U disk management interface to make related operations.
		Other Operations	Click to open the other operation interface, where user can perform copy, deletion, combination, edition and other operations.
		Single/Multiple Selection Shift	Shift between single selection and multiple selections.

Press to enter the interface for other operations of memory pattern (to deal with

any single pattern, user need select the pattern first).





In this interface, press each operation to enter the corresponding interface. Please read the following paragraphs for detailed explanation. Press or b to turn page, and press



to return to memory pattern management interface.

6.2 Select Pattern for Embroidery

- 1. Press to enter memory pattern management interface.
- 2. Select the pattern in the memory pattern image display area.

6.3 Memory Pattern Preview

The selected pattern can be previewed in the memory pattern preview interface to check more details.





No.	Icon	Name	Description
1		Pattern Preview Area	Display the pattern in the appointed method and speed
		Draw/Pause Switch	Shift between drawing pattern and pausing display
		Move up	Move the pattern upwards
		Single Step Display	Draw the pattern by drawing single steps
	(Scale up	Enlarge the pattern in the preview area
2		Scale down	Reduce the pattern in the preview area
		Actual Display	Display the pattern in the actual size. So the size of the pattern on the screen is the actual size of the pattern after embroidery.
		Display to the Size of the Window	Display the pattern accordint to the size of the pattern preview area.
		Move left	Move the pattern leftward
		Move down	Move the pattern downward
Chapter 6 Memory Pattern Management



No.	Icon	Name	Description
		Move right	Move the pattern rightward
	SPEED	Deceleration	Lower the display speed of patterns
2	SPEED	Acceleration	Fasten the display speed of patterns
		Redraw	Redisplay the selected pattern
		Quit	Quit the operation in pattern preview interface

- 1. Press to enter memory pattern management interface.
- 2. Select a pattern in the memory pattern image display area.
- 3. Press to open memory pattern preview interface.
 4. Press Press to control the size of the pattern display.
 Press to control the display position. Press Press to control display speed. Press to shift to the pause status, where the single step of pattern can be displayed. Press to redisplay the selected pattern.

6.4 Pattern Output

User can transfer the pattern data in memory to U disk.

- 1. Press to enter memory pattern management interface
- 2. Select the memory patterns to be outputted







4. System will display the window to "Select U disk" and press to make the selection.

Select UDisk			
1	USB 1	USB 2	
			P

4. Input the pattern name saved in the U disk.

Export Pattern	-		
Pattern N	um	55	
Pattern Na	ame	HUAHUAN	
1 abc	2 def	3 ghi	
4 jkl	5 mno	6 pqr	C
7 stu	8 vwx	9 yz	
	0		

The system provides the minimum available pattern number as the default value. User can use the keypad below to change the number.



5.	Press	of the completion hint.
		Warnning Export Pattern Finishi!
6.	Press	to return to pattern management interface.

6.5 Copy the Memory Pattern

- 1. Press to enter memory pattern management interface.
- 2. Select a pattern in the memory pattern image display area.
- 3. Press to enter memory operation selection interface.
- 4. Click "Copy Pattern" to enter its operation interface. The system will

automatically provide the smallest available pattern number and default pattern name. If

the user doesn't want to change them, please press

5. To input a new pattern number, click "New Pattern number" and input the new number in the pop-up window.





6. To change the new pattern name, click "New Pattern name" and input the new name in the pop-up window.

	Pattern Num	10		_
Original	Pattern Name	e 125	9	
New Pat	1 abc	2 def	3 ghi	
New Pat	4 jkl	5 mno	6 pqr	C
	7 stu	8 vwx	9 y z	•
	A ∽a	0	~	/

7. Press to copy the pattern and return to pattern operation selection interface. Press to cancel the copy operation and return to pattern operation

selection interface.



6.6 Create Outline Pattern

This operation can generate a new pattern based on the outline of the designated pattern.

- 1. Press to enter memory pattern management interface.
- 2. Select a pattern in the memory pattern image display area.
- 3. Press to enter memory operation selection interface.
- 4. Press "Create Outline Pattern" to enter the operation interface.
- 5. User can press to input new pattern number and name instead of default ones.
- 6. Press to create the outline pattern and return to pattern operation selection interface. Press to quit the creating operation and return to pattern operation selection interface.

6.7 Create High-speed Pattern

This function can be used to devide long stitch into short ones, so as to prevent speed reduction due to long stitches.

- 1. Press to enter memory pattern management interface.
- 2. Select a pattern in the memory pattern image display area.
- 3. Press to enter memory operation selection interface.
- 4. Press "Create High-speed Pattern" to enter the operation interface.
- 5. User can press to input new pattern number and name instead of default ones.
- 6. Press violation to create the high-speed pattern and return to pattern operation

selection interface. Press to quit the creating operation and return to pattern operation selection interface.

6.8 Divide Pattern

This operation is to divide one pattern into two new patterns.



- 1. Press to enter memory pattern management interface.
- 2. Select a pattern in the memory pattern image display area.
- 3. Press to enter memory operation selection interface.
- 4. Press "Divide Pattern" to enter the operation interface.
- 5. User can press to input new pattern number and name instead of default ones.
- 6. Press "Divide Stitch" to input the stitch number of the division position.

	C (1)		2 💖	D /	2020-06-04
)) 🎕	/ 2>		3	۹
Divide Par	ttern				
Original Div	ide Stitch		-	_	
Original	Divide Stitc	h 5959	93		
	1	2	3		
1# New	4	5	6	C	
1# New	7	8	9	•	
2# New	+/-	0		/	
2# New					
Divide Stitch	n<1-119186	>		59593	
				_	
1/				$\mathbf{\nabla}$	
N		•			111

7. Press

to divide the pattern into two new patterns and return to pattern

operation selection interface. Press to quit the dividing operation and return to pattern operation selection interface.

6.9 Create Parameter Pattern

This operation is to create a new pattern from the seleted pattern together with the settings of its common parameters and color-changing order.

- 1. Press to enter memory pattern management interface.
- 2. Select a pattern in the memory pattern image display area.



3. Press to enter memor

to enter memory operation selection interface.

4. Press "Create Parameter Pattern" to enter the operation interface.



5. User can press to input new pattern number and name instead of default ones.

6. Press to create the parameter pattern and return to pattern operation selection interface. Press to quit the creating operation and return to pattern operation selection interface.

6.10 Mosaic Pattern

This operation is to combine two patterns into one new pattern. The interval of patterns refers to the distance between the end of the first pattern and the start of the second pattern.

- 1. Press to enter memory pattern management interface.
- 2. Select the two patterns to be combined and record their pattern numbers.
- 3. Press to enter memory operation selection interface.
- 4. Press "Mosaic Pattern" to enter the operation interface.
- 5. User can press to input new pattern number and name instead of default ones.



6. Press "X Interval" to input the value. Press "Y Interval" to input the value.

Mosaic Pattern	
1# Original Pattern Num	1
2# Original Pattern Num	5
New Patern Num	10
New Pattern Name	1259
X Internal <-1000.0-1000.0>	50
Y Internal <-1000.0-1000.0>	0

7. Press to combine patterns and return to pattern operation selection interface. Press to quit the combining operation and return to pattern operation selection interface.

6.11 Create Combined Pattern

The combined pattern means a pattern group combined from several certain (less than 99) memory patterns after setting their parameters. The combined pattern is set as automatic continuous embroidery. To embroider a combined pattern, user need return to the memory pattern management interface after creating or editing the combined pattern, where user can select the combined pattern, and then after embroidery confirmation, press start to embroider.

1. Press to enter memory pattern management interface.

2. To edit existing combined patterns, select a combined pattern; to create a new combined pattern, just follow the instructions below.

- 3. Press to enter memory operation selection interface.
- 4. Press "Create Combined Pattern" to enter the operation interface.



The combined ID shows the current pattern number and how many patterns the combined pattern is composed of. Display form is "pattern number (the total amount of patterns)".

1. 🕫 🕫 🖈	2 NAHAO 16:09 2020-06-08
<mark>- 🗟 🕜 🎲 </mark> 2	> //==1\ 3> 👷 @
Create Combine Pattern	
(1/1)Pattern Num	1
X Zoom Rate <50,200>	100
Y Zoom Rate <50,200>	100
Rotation Angle <0,89>	0
Direction	Р
Prior Mode	Scale Prior
1/1	

5. Set the parameters of the first pattern, including pattern number, scaling ratio, rotating angle, pattern direction and priority mode. Please refer to Chapter 4 for details of the settings.

6. Press **b** to set several patterns for packing. And press **d** to go back to change the parameters of combined patterns.

If the current pattern is not the first of the combined pattern, user need set the interval between it and the first pattern. Please refer to Chapter 4 for details of inputting parameters.



	16:09 2020-06-08
	<u> / / = 1</u> 3) 👷 4
Create Combine Pattern	
(2/2)Pattern Num	5
X Zoom Rate <50,200>	100
Y Zoom Rate <50,200>	100
Rotation Angle <0,89>	0
Direction	Р
Prior Mode	Scale Prior
X Internal Relative to No.1 Pattern <-1000.0-1000.2>	0
Y Internal Relative to No.1 Pattern <-1000.0-1000.2>	0
2/2	V 🖡
enter the operat	ion interface.
enter the operat	ion interface. 2 ↔ PAHAO 1513 222-06-09 ↓ / म € 3 ♀ € € €
enter the operat	ion interface. 2
الله enter the operation الله الله <t< td=""><td>ion interface.</td></t<>	ion interface.
enter the operat	ion interface.
Image: Constraint of the second se	ion interface.
Image: state of the	ion interface. 2 2 10 16:13 2020-08-08 10 10 1259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2259 2250

The system will hint user to input the new pattern number and the new pattern name.

8. Press

7. Press

to

ss 🕞

to save the combined pattern and return to pattern operation

to quit saving and return to pattern operation selection

selection interface. Press interface.



6.12 Satin Stitch Adjustment

This operation is to adjust the satin width in the design according to the need.

- 1. Press to enter memory pattern management interface.
- 2. Select a pattern in the memory pattern image display area.
- 3. Press to enter memory operation selection interface.
- 4. Press "Satin Stitch Adjustment" to enter the operation interface.

r 🕄 🛈 🚚	2 PAHAO 16:21 2020-06-08
<mark>- 🗟 📀 🎲 🔹</mark>	> / 🖬 3> 👷 4
Satin Width Adj.	
Original Pattern Num	1
Original Pattern Name	1259
New Patern Num	10
New Pattern Name	1259
X Adjust Value <-0.2-0.3>	0.1
Y Adjust Value <-0.2-0.3>	0.1
1/1	
N	

- 5. User can press to input new pattern number and name instead of default ones.
- 6. Press "X Adjust Value" and "Y Adjust Value" to input the value respectively.
- 7. Press v to make the satin stitch adjustment and return to pattern operation

selection interface. Press to quit the adjusting operation and return to pattern operation selection interface.



Chapter 7 Letter Pattern Operation

System can generate letter pattern based on the built-in font libraries.

7.1 Enter Main Interface for Letter Embroidery

Press

in the pattern management interface to enter the main interface for letter

embroidery.





7.2 Input Letter String for Embroidery

Press

in the main interface for letter embroidery to enter letter string input

interface.





The upside of the window is the display area and the downside is the operation area. After

inputting the letter string, press

to save.

7.3 Adjust Letter Pattern

1. Letter Pattern Adjustment Interface



There are 4 rows of operation keys in the interface, the first two rows are the file and view



functions keys, the third row are keys for adjusting letter arrangement, and the forth row are keys for adjusting letter string. In the middle of the interface is the letter pattern display area.

Generally, user should set the parameters, such as whole arrangement method, rotate angle and letter interval of the letter string; then select certain letter to adjust the its arrangement parameters.

Letter patten display window: the crosses in the centre are the coordinates and the intersection represents the origin (0, 0). The letter will be arranged around the origin automatically.

2. Keys for Adjusting Selected Letters



"Letter String": edit letter string.

"Change Font": change the font of selected letters. Press this key to display a dialog box, where user can select a desired font and confirm it.

"Color-changing Shift": set or cancel color-changing before the selected letter.

"Selection Shift": shift among selected letters. A letter must be selected before any edit. If a red "+" appears on a letter, it means the letter is selected, such as _____. The system will select all letters as default. Press this key to select the first letter, and press it again to select the second one, and so on. After selecting the last letter, press this key again to select all letters.



"Increase Width": increase width of selected letter. "Reduce Width": reduce width of selected letter.





"Reduce Height": reduce height of selected letter.





"Horizontal Overturn": overturn the selected letter horizontally.



"Vertical Overturn": overturn the selected letter vertically.



"Clockwise Rotation": use the letter as centre ("+" in the centre of letter), and

rotate the selected letter clockwise.

3. View and File Operation

*** "Letter Density": adjust the density of the letter string. Press this key to display

thedensity dialog box, where user can set stitch form, increase or decrease density.

Char Density Dial	og	
	¥-	M +
		X

"Stitch Form": show/hide the stitch form. Hiding the stitch form can improve

operation speed.







"Increase Density": increase the satin stitch density of the created letter pattern.



"Reduce Density": reduce satin stitch density of the created letter pattern.



"Left", "Right", "Up" and "Down": move letter pattern toward

each direction.



"Reduce": reduce to the display window of letter pattern.

"Enlarge": enlarge to show the detailed part of the letter pattern.





"Actual": show the letter pattern in the actual size. At this time, the size of pattern in interface is equal to actual size.

"Center": scale up/down the view, so as to show the whole pattern for checking.

"Save": it is used for saving the edited letter pattern. After pressing this key, the system will display the window for user to input the pattern number and name. According to need, change the pattern name and number (the number is not recommended to be changed), then press confirmation key to start saving.



"Exit": quit from "Create Letter Pattern".

4. Keys for Adjusting Whole Arrangement

If you adjust the parameters for whole rank after the edition of the individual letter, the edition of the individual letter will be probably replaced.

"Horizontal": rank the letters horizontally



Press this key to shift among "horizontal", "vertical", "up arc", and "down arc". Only in case of "up arc" and "down arc" can "fix letter direction", "increase radian" and "decrease radian" be adjusted.



"Vertical": rank letters vertically



"Up Arc": rank letters in arc bending upwards





"Down Arc": rank letters in arc bending downwards



"Fix Letter Direction": when user ranks the letters in arc, the letter angle will not



change along with the position of arc, but fix at a certain angle





"Increase Radian": when user ranks the letters in arc, this key can enlarge the

radian of the reference arc



"Reduce Radian": when user ranks the letters in arc, this key can reduce the radian

of the reference arc





7.4 Save Letter Pattern

After finishing the letter pattern edit, user can press to display a window for user to input pattern number and name, and then press again to save.





After saving, system will return to the main interface for letter embroidery.

If there is no need to edit letter pattern, press to quit and the following hint will be displayed.

		1 Y+:7.1mm	4:-5.1mm Zoo	m:100%		
	uestion					
C	Quit?					
				~		
Θ	()			AB		
	BC	0	2		**	-
				Ded.	A	- C
			-		¥.	K

•

to cancel saving, and return to the pattern

management interface.

to save or press

Press



Chapter 8 Assistant Operation

User can perform some common assistant operations by pressing keys.

8.1 Frame Selection

User can press " keyto enter the interface for frame selection and position.



No.	Icon	Name			
1		Pattern Range Display			
	frame A	Frame Type Selection			
		Position Pattern to the			
		Center of the Frame			
		Frame Parameter Setting			
2		Move Frame along Pattern			
		Outside			
		Move Frame along Pattern			
	e)	Outline			
		Memory of Pattern Origin			



No.	Icon	Name		
2		Recovery of Pattern Origin		
		Set Frame Origin		
		Recover frame position		
		Exit		
		Manual Pattern Movement		

8.2 Set Frame Origin

Setting the frame origin is the premise for saving the pattern's start point and setting frame protection at sudden power-off. So after the installation or maintenance of machine, it's necessary to set the frame origin.

- 1. Press " [20] " key to enter the interface for frame selection and position.
- 2. Press

Ju

to enter frame parameter setting interface.





3. Select "Auto Find Origin Point"



System will move the frame automatically and determine the origin according to the limit switch. So please ensure that the limit switch has been installed into the machine and activated.

8.3 Set Offset Point

The offset point can be set at any point other than the start point. When the machine starts embroidering after the settings, the frame will firstly move from the offset point to the start point and start normal embroidery. After embroidery, the frame will move back to the offset point. Moreover, the offset point is also the standard for frame to move out at appliqué embroidery. The function can only be used under the embroidery confirmation status and before embroidery.

1. In Embroidery Status, click **[[[]**] to have access to the frame selection and position interface.



2. Click the key for setting the offset point

, clear the startpoint.

3. Move the frame to the offset point: Press the frame-moving key to move the frame to the offset point.



4. Click to confirm the operation. System will save the position of the offset point.

8.4 Frame Origin Recovery

After power-off, if the frame is moved, this operation can be used to restore the frame position when power resumes. There are two operations you can do, operation 1:

- 1. In Embroidery Status, click to have access to the frame selection and position interface.



A. The

(for user) to enter parameter

- 3. Click
- to Frame Origin Recovery, click to exit.
- Operation 2:
- 1. Press in the main interface and press setting interface.
- 2. Setting parameters "Whether to boot prompt recover frame position": Click "Yes", and this setting dialog box will automatically pop up when starting up ; Click "No", this operation dialog box will not be prompted when starting up.

🔹 🕅 🕅 🕅 🕅	DAHAO 15:44 2020-07-15
🔺 👌 🖕 📏	
(1) Boring Emb. Disp. C30 <0,12>	0
 High Frame-Shift Speed <1,30> 	16
Whether to boot prompt recover frame position	YES ON OFF
4	
5	
6	
1	
8	
9	
10	
Emb Aux > 3 /	3 🕨 📴
	111

3. When the machine is powered on, "Are sure recover frame position?" dialogue window will pop up automatically.





In the main	n interface 🔀 🔍, press 🕻
	Question
	Would you want clear XY info ?

2. System will set current X/Y value to 0.

User can check the current X/Y value on the main interface.

8.6 Positioning Idling

1.

This operation can only be undertaken under embroidery confirmation status



This function can move the frame to certain position without embroidering according to user's need. User can select color-changing code or stop code as reference to idle forward (or backward).





8.6.1. Low Speed Idling Forward





- In the main interface **_______**, press 1.
- to idle forward at high speed 2. Press

Note: the operation method of high speed idling backward is the same with here.



8.6.4. Go to Next Color

- 1. In the main interface , press , press
- 2. Press 1 = 1 to idle to the next color-changing code

Note: the operation method of "go to previous color" is the same with here.

8.6.5. Forward Idling

- 1. In the main interface , press , press
- 2. Input the stitch number. 4100

System will have access to the interface for inputting the forward stitch number. Customers

need to click to confirm the operation, or click to cancel the operation.

Number Pad		_	
Goto Stitche	es: 100		
1	2	3	
4	5	6	C
7	8	9	•
+/-	0		
			•

3. System returns to the main interface, press is to have the frame float the pointed

position.

8.6.6. Backward Idling

The operations are similar to "Forward Idling". The only difference lies in is to "press





Chapter 9 Assistant Operation Function

These functions are carried out by clicking the keys on the Assistant Operation screen.

Click

to enter Emb helper functions screen.



9.1 Needle Down

This function is designed for whole cloth embroidery (quilt embroidery). After part of the embroidery is finished, the needle will stop and prick into the embroidery cloth to fix it. After user releases the cloth, the machine will move the frame to the designated position. When the cloth is fixed on the frame again, next operation for the embroidery can be performed. This function can only be used under the embroidery confirmation status.

- 1. Click relation to have access to the Assistant Operation interface.
- 2. Click the key of "Needle Down".Confirm needle down action







3. Release cloth, move frame, and then press Enter



Users need to release the cloth and move frame to designated point, then click



confirm.

4. After user confirms the frame-moving, system will returns to the main interface.

Customers need to fix the cloth, and then press the Start to continue embroidering.

9.2 Wifi NetWord Configuration

This function can be used to patterns' transfer by wireless, such as doodle art embroidery, Chinese embroidery, picture embroidery.

There are two ways to set up the WIFI Network Configuration

First method:

1. Press , access to the Assistant Operation interface



2. Press "wifi Configuration", access to wifi network configuration interface



3. Press "wireless network" and set wifi network function, press , and refresh.



4. Chose the network, press "connected", access to the wireless password interface

DAHAO_CXJ						
Password 12345678						
1 abc	2 def	3 ghi				
4 jkl	5 mno	6 pqr	C			
7 stu	8 vwx	9 yz	•			
A	0					



5. enter the password, press , return the

, return the wifi network configuration interface,

- if press , the operation will be canceled
- 6. After wifi network configuration finished, the interface will be like:



7. Wireless connection status: from $\overline{\mathfrak{F}}$ to $\overline{\mathfrak{F}}_{\circ}$.

. 🕄	(X) 💷	2 💖	DAHAO 13:48 2020-06-01				
	* 🞲 / 2	> ∕!∓!∖ (3) 👷 4				
1_1259.DSB	2_1259.D5B	3_1259.D5B	4_1.DST				
5_33333.DST	6_2014-Q-1.DSB	7_3FANG_JP.DST	8_5wh792.DST				
	1/	2					
No. 1 Name 1259.DSI X [-60.1, 2: Y [-102.0, 1	a U 22.8] ↔ 102.1] ‡	23 119186 282.9 204.1	 ⊘ [™] II 				
N							

Second method:

1. In any interface



× 🕅	Ø II (2 💖	DAHAO 13:48 2020-06-01				
	* 2	/₩₩\ 3	۵ 👥 🔇				
1_1259.D58	2_1259.D58	3_1259.DSB	4_1.DST				
5_33333.D5T	33333.DST 6_2014-Q-1.DSB		8_5wh792.DST				
	1/2	2					
No. 1 Name 1259.DSB X [-60.1, 22 Y [-102.0, 1	2 2 1 1 2.8] ↔ 2 02.1] ↓ 2	3 19186 82.9 04.1	○ * ■ Ⅲ				
	**						
N	. <u>•</u> •						

2. Press \widehat{F} , access to wifi network configuration interface

Wifi IP:	
Wireless Local Area Network	
	-
(5)	

3. Follow the same steps as the first method



Chapter 10 Other Functions

These functions can be used during the usage, including machine maintenance,

information inquiry and system settings.

Press to enter the interface for other function, where a list of function keys will be displayed for user to operate by pressing.



The words on the keys can help user understand the functions.

10.1 Statistics

- 1. Press to enter the interface for other functions.
- 2. Press \checkmark to enter the interface of statistics.

Chapter 10 Other Functions



×	<u>ę</u> () 1115 (1	- 💞	DA 09:20	HAO 2020-06-17		
â	\rightarrow	•		\rightarrow			
Tot Boot Tin	ne	4Minute24Second					
Tot Boot Tin	nes		38				
Tot Stitches	¢.		0				
Tot Breakag	e Times		0				
Tot Trimmin	g Test		0				
Tot Color Ch Times	ange		0				
Tot Emb Dis	tance		0				
Index	Pattern Num	Pattern Name	Stitches	Workpiece Num	Detail		
1	0		0	0	Q		
2	0		0	0	Q		
3	0		0	0	Q		
4	0		0	0	Q		
5	0		0	0	Q		
6	0		0	0	Q		
7	0		0	0	Q		
8	0		0	0	Q		
9	0	1	0	0	Q		
10	0		0	0	Q		
6					111		

In the above interface, the statistic information is displayed in a chart. If user need check

EO

details of each pattern, press

to enter the corresponding interface.

DAHAO

		₹~ (I	2) IN		₹¢°	09:21	2020-06-17			
	Â	\geq	-		9 ili					
		-			-	-				
				Detail						
	Pattern Nu	m	#-1	Wor	kpiece Num		0			
	Pattern Na	me		Stit	ch Count		0			
	Stitches		0	Ave	. Work Hour		0 s			
	Color Char Times	ige	0	Max	Work Hour		0 s			
	Breakage	Times	0	Min	Work Hour		0 s			
		-	Break	ane Sta	tistics	1				
	Hea	id 1	2	3	4	5	6			
	N.P 1	0	0	0	0	0	0			
	2	0	0	0	0	0	0			
	3	0	0	0	0	0	0			
	5	0	0	0	0	0	0			
	6	0	0	0	0	0	0			
	7	0	0	0	0	0	0			
	9	0	0	0	0	0	0			
	10	0	0	0	0	0	0			
	11	0	0	0	0	0	0			
	12	0	0	0	0	0	0			
	14	0	0	0	0	0	0			
	15	0	0	0	0	0	0			
		1/4					P			
	1				~		111	1		
Press b to return to th	e int	erfa	ce of	f st	atistic	cs.	Press		to delete s	statistic
information and press	to re	turn							7	





10.2 Machine Debugging

<u>This operation is only for repairman, ordinary users are banned to undertake</u> <u>these operations. Because these operations involve some mechanical work, please pay</u> <u>attention to the personal safety and equipment security during the operation.</u>

Debugging function is to mainly used for testing, maintenance and fault inspection of the machine, which include the following function (debugging items will be differentfor the different models):

Debugging Interface 1	Debugging Interface 2					
	Main Shaft Speed And Encoder Test					
Main Shaft Test	Main Shaft Angle					
	Trimming solenoid/Motor					
	Hold solenoid/Motor					
	Hook Solenoid/Motor					
Trimming/Mac. Head Debug	Hook Solenoid/Motor Continuous Test					
	Head Solenoid/Motor					
	Upper Thread Clamp Test					
Trimming/Mac. Head Debug	Trimming Motor Origin					
Drasha a Data di an	Change needle position, needle bar					
Breakage Detection	color and adjust main shaft manually					
	Sequin Presser Up/Down					
Sequin Test	Sequin Motor A1/B1/C1/D1 Feed					
	Sequin Device Gap Valve Open/Closed					
Simple Rope Emvroidery Test						
	Frame Param test					
	Main shaft parameter test					
Driver Parameter Test	Driver param Import					
	Driver param Export					
	Frame Param Select					
Sensor Status Test	Test pull bar switch, frame limit, knife					
Sensor Status 10st	origin, knife maximum point,					



Debugging Interface 1	Debugging Interface 2
	thread-hooking origin, and needle
	position display, etc.
Peripheral board Management	Peripheral board upgrade
	All Peripheral Board Write Address
	All Peripheral Board Address Check
Boot Loader Upgrade	
Param Export/Import	Import machine parameters
	Export machine parameters
Param Init	
Update Logo	
Touch Screen Calibration	
Function Config	Sequin, Simple Cording, Glass beads
Photo Emb. Authorized	
Special Broidery Authorized	
Machine Debug Authority	
Passwd Change	

10.2.1. Touch Screen Correction

After using for a period, the touch screen may probably have the problem of the inaccurate operation. This problem can be resolved by touch screen correction. During the correction, please touch the very center of the cross displayed on the screen, or it may affect the future operation. In order to avoid the trouble caused by the inaccurate correction, this operation is only for the person with authorization.

Operation 1:

- 1. Press to enter the interface for other functions.
- 2. Press for to enter debugging interface, press "touch screen calibration".



3.



touch screen calibration and return to the interface for other functions.

4. Press the center of the crosses one by one.



During the process of correction, a lot of crosses will appear on the screen. User should press the center of them. System receives the data of those points and saves them as standard data for correction.

5. System will make correction according to the coordinates of points pressed by users.

System will make the correction and then return to the interface for other functions automatically.

Operation 2:


1. Press when the initialization interface display until enter to the touch

screen correction interface

2. Press the center of the crosses one by one according to the prompt, and abandon the touch screen calibration, then restart system, should be normal when touch any position of the screen.



10.2.2. Function Configuration

Is should display the related functions and parameters in machine parameter, assistant operation and debugging interface. For example, Sequin function configuration, in function configuration, chose 'sequin', and check machine parameter, assistant operation and debugging interface, the related sequin functions and parameters will be displayed.

- 1. Press to enter the interface for other functions.
- 2. Press **T** to enter debugging interface, press "Function Config".





3. Access to function configuration interface, press 'sequin'

1	Sequin	
2	Taping.emb	
3	Glass beads	
		P

10.3 Language

System supports Chinese, English, Turkish, Spanish, and so on.

1. Press to enter the interface for other functions.



2. Press to enter language interface.

🕵 🕄 🔞 채 🗌 💞 DAHAO	■ 🕄 🔞 坑 🗋 🏕 DAHAO
1 👾 🕈	(1) German
2 English	2 Italian
عربى	3 Polish
👍 💽 Türk	فارسی 🚽
6 El español	5
🤞 🔤 русский 🔲	6
🗇 🧿 Português	$\overline{\mathcal{T}}$
8 Français	8
Thai	9
10 Holland	(1)
 ✓ 1/2 ▶ 	< 2/2
	N 4 🕂 🕅

Select the language you want and system will enter the main interface in the selected language.

10.4 Date Set

In date set interface, user can check and modify the date and time of the system.

10.5 Information

Operation Procedures:



2. Press 1



2 🕄 🕄) 沈 🗋 📌 DAHAO
Machine ID	01012CB9C40407580BF980D5CC91DEA0
Upper Computer Software Ver.	debug 0/18
additional inf	ODI2NDU2
Lower Computer Ver.	AX54MS0GQ73A11
Lower Computer Ver. Date	200427
Lower Computer Inner Ver.	159
	2020-06-17711:18:15
Lower Computer Boot Ver.	MX5_UPDATE0101
Lower Computer Boot Ver. Date	180428
Lower Computer Boot Inner Ver.	019
Peripheral pc2220 version	PC2220_TY_V1.4
Version date	200323_15:13:12
Internal version	V1408_HeHe
1/1	
N	• - 11

to quit.

This function will help user check machine software information. Press Note: You can view the peripheral board pc2220, and the software must be above 3.0.



Chapter 11 About JF Sequin Embroidery

11.1 Brief of Sequin Embroidery

Sequin embroidery is formed by many sequins and the specific stitch form. Because the sequins are made of the hard and shining material with smooth surface, the sequin embroidery, formed by the sequins with different colors, shapes and sizes, features the unique shining effect. The design with sequin code has its own pattern format.

JF Type multi-sequin embroidery is divided into two types on the designs: one is normal multi-sequin design, made by the traditional pattern-making method; the other is special multi-sequin design, made by the normal design software with the special pattern-making rules.

For normal multi-sequin design, user should set sequin mode when modifying the colorchanging order. But the special multi-sequin design can be directly embroidered only after modification of color-changing order, which means user doesn't need to set the sequin mode.

Meanwhile, the machine can automatically change normal design to special design during the process of design import. The new special design saves the entire sequins in the original normal design as sequin A. If you want further modification, you can use "Sequin Edition" to modify. The multi-sequin design after the modification is the special multi-sequin design.

I . Application Range

This system is applicable to the sequin embroidery control system that combines normal embroidery mechanism, zigzag embroidery device and sequin-feeding mechanism.

II .Features

1. Support two sequin-feeding method: Wheel and Lever;

Wheel: The core part for feeding the sequins within this device is the mechanism like a wheel, which transports the sequins to the proper position by rotating in the single direction.

Lever: The core part for feeding the sequins within this device is a lever mechanism, which will send the sequins to their positions with its alternating motion.

- 2. Separate action of sequin-mending and sequin-feeding device;
- 3. Manual separate or collective feeding at single time;
- 4. Separate display of the working statuses of sequin device;



5. Sequin-feeding method and the feeding angle can be changed via the operation panel.

- III. Specifications
 - 1. Size of Sequin available: Diameters at 3mm, 4mm, 5mm, 6.75mm and 9mm;
 - 2. Max speed at 1000rpm.

11.2 Embroidery Procedure of Sequin

At sequin embroidery, user needs to follow the procedure at below: 1.

Input design with sequin code, refer to 11.3

- 2. If necessary, please transform and edit the design, please refer to 11.4);
- 3. Set the sequin parameter according to the setting instructions in 11.5.
- 4. Check and adjust the sequin-feeding device (Refer to 11.7), so as to make sure the sequin-feeding device works normally;

5. Set color-changing order (Refer to 错误!未找到引用源。)

- 6. Return to main interface and confirm the embroidery;
- 7. Start embroidery.

Attention: during the embroidery, don't dial the manual switch for moving the valve, or it will cause the damage of the sequin-feeding device.

11.3 Input Sequin Design

Press in the design management to enter disk selection interface to open the disk needed. After selecting design for input, user needs press to "Whether support multiple gold or not", choosing " " is to save it as the special sequin design no matter what is was. For the normal sequin designs, the changed sequin designs will save all the multi-sequin within the original design as "A" type sequin. If you choose " F", normal sequin designs remain as they are, while special multi-sequin designs will be saved as special multi-sequin design.





Enter to have access to the design input interface as shown in below:

Import Patte	rn			
Pattern N	lum	55		
Pattern N	ame	3	金片-19	
1 abc	de	2 ef	3 ghi	
4 jkl	t mi	no	6 pqr	C
7 stu	۲. ۲.v	3 v x	9 y z	•
A ∽a	C)		

Setting procedures: User should input number and name of pattern.

11.4 Edit Sequin Design

This function is to edit sequin design within the system. After edition, all the designs will be saved as special multi-sequin design. User doesn't need set the sequin mode at modifying the color-changing order

In the "Pattern Management" interface, select sequin design for edition. Click
 "###", "Edit Gold Picec Pattern" in order to enter the "Edit Design" interface.



2.

(+)

3. Click

original size



BC

ACD BCD

ABC

to shift the current stitch mode between "navigating by position" and

"navigating by stitch number". "navigating by position": when you press direction

D

ABCD

. . .

BD

ABD

4. Click



keys, the next stitch code in that direction will be selected, regardless at its stitch number. "navigating by stitch number": when you press direction keys "leftward" or "upward", the last sequin stitch code (smaller than the current number) will be selected; when you press "rightward" or "downward", the next sequin stitch code (bigger than the current number) will be selected.

5. Click to enter into "Sequin Range Edit".

Set Arear Start Stitch	
Set Arear Eed Stitch	
Cancel Select Arear	
Employ Alternant Golod Piece	
Select Current Color Change	
	P

- (1) Move the cursor to a stitch position, then click "Set Range Start Stitch" to set the current stitch as the start stitch of this area. Move the cursor to a different stitch position, then click "Set Range End Stitch". The area for setting is from the start stitch to end stitch.
- (2) If you want to cancel the area, click "Cancel Range".
- 6. Sequin Mode Selection

There are 15 kinds of sequin modes for customers to select, including A, B, AB, C, AC, BC, ABC, D, AD, BD, ABD, CD, ACD, BCD and ABCD.

Names of these 4 sequins: A, B, C and D. If these 4 sequins are delivered at same time, then A will be on the top, then B, C and D.





7. Edition of Alternating Sequin

If you want to use the alternating sequin, you should define a range for using them at first. In " , use "Set Range Start Stitch" and "Set Range End Stitch" or "Select Current Color Range" to set sequin range. After that, use "Edit Alternating Sequin" in " ; to set the alternating sequin used.



B, C and D.



b) After that, press 🗸 to confirm the sequin-feeding mode. Then the system will

ask user to input the number of sequins fed. Click the number keys to input the number

(Range: 0~9999). If a sequin group is only used for one stitch at the embroidery cycle, user

will need to input "1" and then press \checkmark

c) Click or with the setting.

For instance, if the current sequin mode is A2ABCD1CD1, the design will be like the one at below:



8. Save

When you finish the edition, click

to save the design.

Pattern Nu	um	15		
Pattern Na	ame	FANG-J	Ρ	
1 abc	2 def		3 ghi	
4 jkl	5 mno		6 pqr	C
7 stu	8 vwx		9 y z	•
A	0		~	/



Input design number and name, then click



to save the edited sequin design, or

click **to cancel the saving**.

11.5 Setting of Multi-Sequin Embroidery Parameters

In this section, we will introduce how to adjust sequin device and the parameters used in multi-sequin embroidery.

Press in the main interface, select "Expert Param" \ge_{44} to enter parameter

management interface, then select Sequin Parameters to have access to the interface for setting

the sequin parameters.

1. Limited Speed for Sequin R(L):

The parameter is to set the max speed during normal embroidery.

Note: the maximum speed of flat embroidery should be higher or equal to speed for sequin embroidery.

2. L/R Sequin Feeding Angle Adjustment

This parameter is to adjust the sequin-feeding angle.

3. Auto Start for Sequin

When the setting is "Yes", system will start embroidering sequin automatically.

When the setting is "No", machine needs manually start at sequin embroidery.

4. Time of Sequin Action

This is to set the time from sequin device going down to starting embroidery (0-15, the default value is 2). If the sequin-feeding device is controlled by valve, use the default value; if that device is controlled by motor, please set it at $4\sim5$.

5. Sequin off after T.B.

When the setting is "Yes", sequin presser foot will be up automatically in case of threadbreakage.

When the setting is "No", the user needs to lift the presser foot manually at threadbreakage.

6. Sequin Ind. Up/Down

When the setting is "Yes", the sequin devices will move independently. When the setting is "No", they will move collectively

7. Lift Valve at Jump without Trim (Y/N)

8. Base of Shift Travel at L/R Motor



- 9. Multiple of Shift Travel at L/R Motor
- 10. Has Origin at Shifting L/R Motor

The parameter No.8, No.9 and No.10 are for the special sequin device that uses the motor (Single Needle Double Sequin) to shift the travel between large sequins and small sequins. There are two kinds of device: one has the shift origin; the other has no shift origin.

11. Beam-breakage Detection Sen.

This parameter is used for the beam embroidery device. "0" is to turn off the sensitivity, the range of this parameter is $0\sim10$. The smaller value means the higher sensitivity of the detection device.

12. Motor Number of L/R Sequin

The setting of this parameter should be based on actual device condition, if there is no sequin device, please set it at 0.

13. Set 3/4/5/6.75/9mm of L/R Sequin

This parameter group is to set the sequin delivery angle. If it is wheel type sequin-feeding device, please set it at single way; if it is lever type sequin-feeding device, please set it at double ways. The parameters of this type are set correctly when the machine is produced. This kind of parameters is closely related to "left/right sequin device A/B/C/D size and color". For example, "A size&color of R sequin" is set to "4mm X color", and then the angle value should be the one in "Set 4MM of R Sequin".

14. A/B/C/D Size &Color of R/L Sequin

The setting of this parameter should depend on the mechanical structure. The corresponded order from A to D is front motor to back motor.

Note: "Motor Number of L/R Sequin" is closely related to the number of A/B/C/D in "A/B/C/D Size&Color of R/L Sequin". For example, if "Motor Number of L/R Sequin" is set to 2, then only the "A/B size&color of R/L sequin" will be displayed.

15. Sequin Gap Num. of L/R Sequin

This is to set gap number. If there is no gap, then it should be set to 0.

16. L/R Sequin Valve Action Time

This parameter is for setting the response time at adjusting the valve action. The larger value means the longer response time. Please set it according to the actual condition of device. Default value of it is 2.

17. L/R Trimmer Action Angle Adj.

This parameter is used at the special sequin device that uses motor to cut the sequin for adjusting the start time of the sequin-cutting motor. The default value of it is 15. The smaller



(1) Click

value means the earlier action of motor, the range of this value is 0~31.

11.6 Manual Operation of Sequin Embroidery

The manual operation part contains "Sequin Start", "Sequin End" and "Sequin-feeding".

- for selecting "sequin start" to let all the presser feet get down;
- (2) Click for selecting "sequin end" to lift all the presser feet;
- (3) Click for selecting "send sequin"; the activated machine heads will send a

sequin at each clicking (with presser foot at down position).

11.7 Debugging Multi-Sequin Embroidery



Location of Sequin Switch Board

1. Operation of Sequin Switch

(1) Manual Operation for Front Motor Sending A Sequin

Put the sequin switch to the down position, dial the thread-breakage detection switch to turn on the green indicator and press manual sequin-feeding button.

(2) Manual Operation for Middle Motor Sending B Sequin

Put the sequin switch to the down position, dial the thread-breakage detection switch to turn on the red indicator and press manual sequin-feeding button.

(3) Manual Operation for Rear Motor Sending C Sequin

Put the sequin switch to the down position, dial the thread-breakage detection switch to turn off the head indicator (dial it to down position too) and press manual sequin-feeding button.



Note: In order to debug the multi-sequin function, user needs to install an external head switch on the single head machine.

2. Debugging Menu of Sequin

Press and then press "machine debugging"

. Then press "Sequin Device

Operations" to show the following image::

(1) Sequin Presser Up	(1) Sequin Diver 3 Gap Valve Open
2 Sequin Presser Down	(12) Sequin Diver 3 Gap Valve Closed
3 Sequin Motor A1 Feed	
(4) Sequin Motor B1 Feed	
5 Sequin Motor C1 Feed	
6 Sequin Motor D1 Feed	
Sequin Diver 1 Gap Valve Open	
8 Sequin Diver 1 Gap Valve Closed	
Sequin Diver 2 Gap Valve Open	
(1) Sequin Diver 2 Gap Valve Closed	

Then you can select related operation for debugging.

11.8 Sequin Mending

After the thread breaks or the red thread-breakage detection indicator is turned on manually, press the stop key to retreat and have the system enter the mending status. At mending status, the sequin devices will go up and the machine will return and stop at the mending point. Then user can press the Start key to perform the mending embroidery for sequin. The mending embroidery will turn to the normal embroidery at the thread-breakage point. Among the machine parameters, the "Patch Count" is unavailable in the in sequin mending operation.



Chapter 12 Operation of Zigzag Embroidery

12.1 Functions

1. Zigzag Embroidery (ZIG Embroidery): this function is to make the thread form the design with certain stitch forms, which have been saved in the computer in advance, the Z4 and Z5. The figures of these two kind of ZIG embroidery are shown at below:



- 2. User can set the max speed for flat embroidery and the top speed for zigzag embroidery respectively.
- 3. Auto saving of the stop point of the M axis: M axis will return to the stop point when the power resumes.
- 4. Thread-trimming for Zigzag Function (Trim bottom thread Only)
- 5. Before manual frame-moving, the zigzag device can lift the presser automatically, while it can also lower the presser before the embroidery.

12.2 Key Technical Indexes

- 1. Speed of Zigzag: 300~850rpm, unit: 10rpm.
- 2 $_{\rm N}$ M Axis Manual/ Auto Rotation Step: $18^\circ\,$ /Step.

12.3 Procedure of Zigzag Embroidery

- Input zigzag embroidery design, then select, adjust and edit the design according to needs;
- (2) Change parameter, select color-changing order and decide embroidery mode;
- (3) Check zigzag embroidery position, and make sure it works normally;
- (4) Start Embroidery

12.4 Related Parameter and Setting Mode

in the main interface, select "Expert Param" $\mathbb{Z}_{\mathbb{A}}$, then user can set

Press



the parameters relating to the zigzag embroidery.

- Right Zigzag Device: Y (N) Y means the first needle is the zigzag embroidery position.
- 2. Left Zigzag Device: Y (N) Y means the last needle is the zigzag embroidery position.
- 3. Zigzag Device Move Time: 2 (Default Value) User should set this value according to the actual action time of zigzag device.
- 4. Top Speed of Zigzag: 600 (Default Value). The top speed can be set to 850rpm, but user needs set it on basis of the actual condition of machine.
- 5. Swing Range of Zigzag: 100 (Default Value). This value is the rotating angle of the wheel. At the circumstance of thread-floating, user can decrease this value to relax the influence as an assistant method. Generally, this value should be no less than 80.
- 6. Frame Swing of Z5 Embroidery: by adjusting the frame, user can change the embroidery range (The senior users are recommended to use this parameter).
- 7. Zigzag Thread-loosing Adjustment Value: this is to adjust the thread-sending speed of all the thread-loosing motors. The recommended value is 9.
- 8. Zigzag Right Device Origin: this is for the angle between the threading point and the direction of the mechanical origin of zigzag device at first needle position. Angle = Parameter value *0.9. For an example, the parameter value is 80; the angle will be 80*0.9=72°.
- 9. Zigzag Left Device Origin: this is for the angle between the threading point and the direction of the mechanical origin of zigzag device at last needle position. Angle = Parameter value *0.9. For an example, the parameter value is 80; the angle will be 80*0.9=72°.
- 10. Greateff mode: $5(1 \sim 5)$
- 11. Work mode: $2(1 \sim 5)$
- 12. Actuation time adj: $50(1 \sim 20)$
- 13. Looped time: 50(30~100)
- 14. Whether cut line when jump: Yes/No.



- 15. Thread-loosing Motor for Zigzag Embroidery: Yes/No. if the device is double motor taping device, user needs to set it at "Y", or user should set it as "N".
- 16. Zigzag Device Movement Detection: Test whether the device moves to the proper position. User needs set this parameter according to the actual condition of the device.
- 17. Test Thread-sending Motor of Zigzag Device (Y/N): The default value is "Y". "Y": the thread-sending motor will not rotate until the position of hall component is checked. "N": The thread-sending motor will run as long as the system is at embroidery status, regardless the position of the hall component. It can only be used at the "107-P03-1.0" and higher version (for PC107 Board) or the "107B-JY-1.0 & 107B-DB-1.0" and higher version (for PC107B Board).

12.5 Relative Operations of Zigzag Embroidery

12.5.1. Shift between Flat Embroidery Position and Zigzag Embroidery

Position

(1) Manual Shift

In the main interface, press the key **III** to enter into color-changing interface.



The

indicates the embroidery mode of the current zigzag embroidery. Click that



key to change the embroidery mode. If user has nothing to change, please press exit.





Definition of icons:

Normal Embroidery;

Z4 Embroidery: The rod swings at each stitch.

5 Z5 Embroidery: The feature of it is same to Z4. It is suitable for the thick thread. (Refer to the parameter: Swinging scope of frame in Zigzag sewing)

(2)Automatic Shift

Before embroidering, automatic shift can be achieved through setting the color-changing position.

In the main interface, press " Zeller" to enter into color changing interface, and then press the key 1 (zigzag head) to change zigzag embroidery mode:



Press the corresponding icon to select the very zigzag embroidery mode, if you don't want to

change, and then press to exit. After confirmation of the embroidery mode and the setting of color-changing order, the system will display as below:

4	4	¥4
3	3	
2	2	
1	1	

12.5.2. M Axis Operation of Zigzag Embroidery

The operations about M axis contain "M axis to be ready", "M axis to cycle" and "M axis to turn", which are all in the Assistant Functions. In the main interface, you can click to enter into the "Assistant Operation" interface. Turn the page, then you can see the parameters "M axis to be ready", "M axis to cycle", "M axis rotate left manual" and "M axis rotate right manual" displayed in order..

(1) Return M Axis to Working Point

Press the key "M axis to be ready" and click M axis back to the working point, click to exit.

on the

on the dialogue window to let the



(2) Return the M-axis to the Origin Point (Step Moving)

Press the key "M axis to cycle" and click axis rotate to the "Zero point", click

on the dialogue window to let the M to exit the operation.

(3) M axis rotate left manual

Press the key "M axis rotate left manual" to let the M axis rotate to the left. It will rotate

18° left once you click the button. After 20 times click, it will return to its origin;

(4) M axis rotate right manual

Press the key "M axis rotate left manual" to let the M axis rotate to the right. It will rotate

18° right once you click the button as well. After 20 times click, it will return to its origin.



Chapter 13 Taping Embroidery

13.1 Function Introductions

- Taping function: Tape can be used as embroidery material. It includes taping 1 122 and taping 2 122 (blind embroidery)
- The presser of special embroidery can go up and down automatically or manually. (This function is only for the machines installed with relevant apparatus)
- 3. The highest speeds of flat embroidery head and special embroidery head can be set respectively.
- 4. Auto-saving of the M axis stop point at power-off: The machine can continue the work from the stop point when the power recovers.
- 5. The trimming function of the special embroidery head (no trim\trim the bottom thread\trim both the upper and bottom threads)
- 6. The presser of special embroidery can go up automatically before manual framemoving and go down before embroidery.

13.2 Main Technical Specification

- 1. Speed of special Embroidery: 300—850rpm, adjusting step at 10r/m.
- 2. Manual rotating angle of M-axis: 18° /step.

13.3 Parameters and setting

Press in the main interface, select "Expert Param", then user can set the parameters relating to the zigzag embroidery.

The remarks of these parameters are at below:

- 1. D28 Special Head Interval:.Range: 10~1000
- 2. D30 Clamp Foot Displace: 0~90

This parameter is to adjust the lifting height of clamp foot at each stitch.

3. D40 Adj Clamp Foot Limit: 0~250

This parameter is the Max height of the clamp foot.



4. D31 Rod Pos. of ZIG: Left/ Right

The "ROD POS. OF ZIG" determines the position of swing rod when M axis is in origin. This parameter must be set in accordance with actual mechanical position.

5. C38 Swing Value of ZIG $(0 \sim 10)$

The parameter is for Z5 embroidery and applies to thick cords. For thick cord embroidery, at Z5 embroidery, the system moves the frame to compensate the swinging scope of the lever.

6. D42 Rotary Gap of M Axis: 0~10

The M axis of special embroidery head has mechanical gap, so it will generate the mechanical difference after M axis changes rotating direction repeatedly. At embroidering the flat tapes, if the shape of tape is curve and the M axis has no angle compensation, the needle will fall at the edge of the tape instead of the right position at each turning.

Adjusting this parameter value is to ensure that the needle falls in the center of tape. During machine debugging, parameter value should be "0" when needle falls in the center of tape. If not, please repeat the adjustment to realize the best effect.

Generally, this parameter should be managed by professional experts before leaving factory.

7. D44 M Axis Work OFF Angle: 0,90

In normal and sequin embroidery, if this parameter is set at 0, the M axis will stop at the horizontal position; if it is set at 90, the M axis will stop at the vertical position. When the distance between the normal embroidery head and special embroidery head is small, this parameter must be set as 90° to avoid crashing.

8. D39 Z Shift Control Angle: 0~180

When the rotating angle is larger than the set value, the Z axis will wing faster.

9. D41 Adj Zig Rod Angle: 1~3

It is the starting angle of the rod, which indicates the relative position of the needle bar and thread. It is used for adjusting the embroidery quality. "1" means the swing starts at an early angle; "2" means the swing postpones certain angle; "3" indicates the swing postpones certain angle again and starts.

10. C36 Ratio of Coil Emb. (The ratio of coiling) : "1~4 Sti/L"



The parameter can change the coiling density; e.g. the set value 2 means one coiling every two stitches.

13.4 Relative Operations of Special Embroidery

13.4.1. Shift between Flat Stitch Head and Special Head

(1) Manual Shift

In the main interface, press the key

to enter into color-changing interface.





indicates the embroidery mode of the current zigzag embroidery. Click that

key to change the embroidery mode. If user has nothing to change, please press exit.

Definition of icons:



Before embroidering, automatic shift can be achieved through setting the color-changing position.

to



In the main interface, press "

press the key (zigzag head) to change zigzag embroidery mode:

R	() Y*	靠1		DA 10:25	HAO 2016-04-12
	ightarrow s	3/			<u>.</u>
	Sec.		00226		
	4		•	4	
		2	1	₹2	
No. Name X Y	₹3	₹4	≥₅	6	nin .0mm .0mm
1 2 3 4 5 6 7 8	2 3 4 C 5 6 7 8	816° 816°	4 1 7 1 0 1 3 1 3	5 8 11 14	3 6 9 12 15

Press the corresponding icon to select the very zigzag embroidery mode, if you don't want to

change, and then press to exit. After confirmation of the embroidery mode and the setting of color-changing order, the system will display as below:

1	11	
2	2	
3	3	
4	1	1

13.4.2. M Axis Operation of Special Embroidery

The operations about M axis contain "M axis to be ready", "M axis to cycle" and "M axis to turn", which are all in the Assistant Functions. In the main interface, you can click **or enter** into the "Assistant Operation" interface. Turn the page, then you can see the parameters "M axis to be ready", "M axis to cycle", "M axis rotate left manual" and "M axis rotate right manual" displayed in order..

(1) Return M Axis to Working Point



Press the key "M axis to be ready" and click

M axis back to the working point, click

to exit.

on the dialogue window to let the

(2) Return the M-axis to the Origin Point (Step Moving)

Press the key "M axis to cycle" and click on the dialogue window to let the M axis rotate to the "Zero point", click to exit the operation.

 $(3) \ M \ axis \ rotate \ left \ manual$

Press the key "M axis rotate left manual" to let the M axis rotate to the left. It will rotate 18° left once you click the button. After 20 ti mes click, it will return to its origin;

(4) M axis rotate right manual

Press the key "M axis rotate left manual" to let the M axis rotate to the right. It will rotate

18° right once you click the button as well. After 20 times click, it will return to its origin.

13.4.3. Operations of Clamp Foot

In the main screen, click to enter into the "Assistant Embroidery Operation" screen, select to "Nipple up", then press " vito lift the clamp foot, select " vito exit.

In the main screen, click to enter into the "Assistant Embroidery Operation" screen, select to "Nipple down", then press " vo lift the clamp foot, select " vo exit.

13.5 Debugging Special Embroidery

Debugging special embroidery mainly includes Zigzag swing to its origin and test of clamp foot action. In the main screen, click to "Machine Test" and then click "Taping" to have access to the screen of machine test.

1. Zigzag rod to 100



Move cursor to "Sway Zig Rod to 100". According to the hint in dialogue window, user

can pull bar to let all the swing rods act once. Click " **to exit**." to exit.

Users can adjust swing range by using this function.

2. Clamp Foot Up/ down

Move cursor to "Test lift clamp foot". According to the hint in dialogue window, user can pull bar to let all the clamp feet go up/down. Pull the bar again to let them down/up again.

Click " **The second sec**

13.6 Steps on Special Embroidery

- 1. Input design, carry out design selection, changing and editing according to requirement.
- 2. Modify the relating parameters, select color-changing order and choose the special embroidery mode.
- 3. Check special heads and make sure they are in perfect condition.
- 4. Pull bar to start embroidering.

13.7 Mechanical Category and Driving Mode Selection for Special Embroidery Machines

Taping machines have three types of the motion parts in the sense of mechanics. We define them as M axis, E axis and clamp foot axis. M axis rotates a certain degrees at every stitch to trace the stitch, which ensures cords or tapes always in front of needle movement. E axis swings once at every one or two stitch to make the Zigzag embroidery. Clamp foot axis is used for lifting and lowering the clamp foot.

1. Maxis

The mechanism of M axis can be divided to two types. One is with clutch device, whose action is controlled by electric valve or by hand. Its advantage is that only the M axis of the patching embroidery is moving and non-patching embroidery heads stay still at mending. This will enhance the quality and efficiency of mending. The other type is without clutch device. Both of the two types are driven by servomotor and the origins of their M axis are positioned by proximity switch.



2. E axis

According to the difference in motor and the equipment of proximity switch for positioning the origin, E axis devices can be divided to the following types:

- 1) Driven by stepping motor separately, without proximity switch for positioning origin
 - 2) Driven by stepping motor collectively, with proximity switch for positioning origin
- 3) Driven by stepping motor collectively, without proximity switch for positioning
- 4) Driven by servomotor, with proximity switch for positioning origin
- 3. Clamp foot axis

The working progress of the special clamp foot is shown at below: (The clamp foot working height is the distance of the foot's movement at every stitch. The clamp foot rising height is the foot's moving distance from the bottom to the upper point at non-embroidery mode. And it's also called the clamp foot limited height.)



Chapter 14 Online Update of Main Software

Update Procedure :

- 1. Hold pressing () and power on.
- 2. The screen will display the following interface, where user should select "update program"

	Update Program	
81	Board Test	
	Language	
į	Infomation	
((via U disk)	

3. Select the update method

Update Program
Select the update mode
Ð
Language



4. System will display the window to "Select U Disk", and select the target U disk.



5. After entering the interface of the U disk, select the program to be updated.

file select list					
001. DST DH04. DSB A15-Std-V1_0_2-20171110. dh					
 1/2 					
file info					
file name: A15-Std-V1_0_2-20171110. dh					
file size: 117. 121MB					
update file describe:					
update file version : V1. 0. 2					



7. When finishing update, system will automatically display a hint "update completed, if no others, please restart", and then please restart.



Chapter 15 Update of Software in Peripheral Board

Update Procedure:

1. Press to enter the interface for other functions.



2. Press to

to enter the interface of statistics.



3. Select "peripheral board management" to enter the management interface, where user should select "peripheral board update".

	1 Peripheral Board Update
	2 All Peripheral Board Write Address
	3 Single Peripheral Board Write Address
	(4) All Peripheral Board Address Check
	5 Single Peripheral Board Address Check
	6 Peripheral Board Infomation
4. Press	
	① USB1: /



6.

5. Select the U disk



7. when system hint successful update, the update is completed.





No.	Name of Parameter	Default Value	Range of Value	Remarks		
Common Parameters						
A01	Direction	Р	p			
A02	Rotate	0	0~89	Rotating angle of the design		
A03	X&Y Scales	100/100	50%~200%	Scale ratio of design in X /Y direction		
A04	Prior Mode	Rotate	Rotate, Scale			
A05	Rep. Mode	Normal	Normal Part	Not used		
A06	Rep. Prior	X Prior	X prior, Y prior			
A07	X&Y Reps	1/1	1~99			
A08	X&Y Interval	0.0/0.0	-999.9~+999.9			
Embroidery Assistant Parameters						
B01	Auto Origin	Yes	No, Yes			
B02	To Do Cyclic Emb.	No	No, Yes	Whether to automatically repeat embroidering the design. It often accompanies repetition or the special design.		
B13	Start for Same Colors	Yes	No, Yes	Whether to start in color-changing way when the later needle position is same to the former one		
D15	Slow STI. After Patch	0	0~3000			
D16	Speed After Patch	850	80~1000			
B18	Support 3D?	Yes	No, Yes			
C77	Filter Short Stitch	Yes	No, Yes	It is fit for high-speed machine using dahao servo-motor driver. It only get effective after user confirm the embroidery again.		
C78	Filtering Short Sti Len	0.5mm	0.1mm~0.6mm	The same as above		
C80	Auto Jump Stitch Len	6mm	6.0mm~12.0mm	The same to above		
U57	Speed of Fast Idling	10	1~10			

Appendix 1 Parameter List


No.	Name of Parameter	Default Value	Range of Value	Remarks	
Thread-breakage Detection Parameters					
B05	T. B. Detect	No	No, Yes		
B11	Sti. Not T.B. Detect	8 stitch	0 stitch ~15 stitch		
B06	Stop after T.B. detect	Yes	No, Yes		
B08	T.B. Back Sti.	0 stitch	0 stitch ~7 stitch		
B09	Back&Patch Count	2 stitch	1 stitch ~9 stitch	How many stitches to patch before the thread break point	
B10	Motion After Patch	Speed Down	Speed No Change, Speed Down, Stop		
B14	Set All Heads Patch	No	No, Yes	If "Yes", all unclosed heads do patching when patching.	
B12	T. B. Detect When Jump	No	No, Yes		
C28	T.B.Detect Debouncing Sti	1 stitch	1 stitch ~6 stitch		
C67	Upper Line Det. Sensitivity	3	1~10		
C68	Bobbin line Det.Sensitivity	5	1~10		
C69	Upper Line Det. Debouncing Sti	1 Sti	1~10 Sti.		
C70	Bobbin line Det. Debouncing Sti	5 Sti	1~10 Sti.		
C90	T.B.D Device Type	Wheel	Spring, Wheel, Spring+Wheel		
C91	Head motor Action Angle	0	0~10		
K1	Fault det.board type	PC2220	PC2220,Other		
L01	T.B. Sound	3 time	No voice, 1~4 time		
P05	Upper Thread Hold Solenoid Type.	Self lock	Self lock, General		
		Fran	ne Parameter		
B03	Over frame by Step	No	No, Yes		



No.	Name of Parameter	Default Value	Range of Value	Remarks
C15	High Frame-Shift Speed	16	1~30	
C16	Low Frame-Shift Speed	12	1~30	
D13	Speed When Over frame	16	0,1,2,,30	
		Main S	haft Parameters	
C07	Max. Speed	1100	250, 300, 350,,1200	
C09	Minimum Speed	400	250,300,350,,600	
C08	Shift Stitch Length (mm)	3	 1.0~10.0(common type machine), 3.0~ 6.0 (high-speed machine using Dahao servo-motor driver) 	When the stitch length is longer than the set value, the machine will lower the speed.
C10	Jump Stitch Speed	600	400~850(common type machine), 400~ 1100 (high-speed machine using Dahao servo-motor driver)	Set the rotation speed for jump stitch.
C13	Set Run Speed	80	80, 90,, 150	
C12	Startup Stitches	2 stitch	1 stitch~9 stitch	Set the startup stitch number before acceleration.
D02	Startup Acce.	15	1,2,3,,30	Increase the value to bring a quicker speedup after pressing the start key.
C25	Set Break Para.	5	0~30	Range: 0~30. When the main shaft motor is an electromagnetic motor, the value is usually set at 9. When it is a servomotor, the parameter is usually set at 5-7.
C24	Main Motor Para.	4	0~30	The parameter is invalid when it's a servomotor. When it's an electromagnetic motor, increase this parameter value to avoid main shaft vibration during braking. Usually it's set as 1.
D14	Stop Ok bef. Pull Bar	Yes	No, Yes	
D10	Ratio of AC	0	-15% ~ +15%	The parameter is used when



No.	Name of Parameter	Default Value	Range of Value	Remarks
	Induction			the main shaft uses induction
				motor. If the value is incorrect,
				the set rotation speed will be
				different from the virtual
				speed.
C05	Value for Thick	0	0.2	
05	Cloth	0	0~3	
C26	Para. Of Needle	15	0.20	
C20	Down	15	0~30	
D52	Lock Motor When	Vas	No. Voc	
D33	Stop	105	110, 105	
C14	Speed of Slow	80	80.400	
C14	Emb	80	80,400	
MS10	Emb.Speed	Middle	Low,Middle,H	
		Thread-tri	mming Parameters	
C01	Jump & Trim	2 1	No Trim, 1 Jump~7	
COI		3 Jump	Jump	
D04	Sucod officer Trime	80	(0.70.90 150	The parameter sets the rotation
D04	Speed after 1 mm		00,70,80130	speed for lock stitch.
C11	Slow Stitches After Trim	3 stitch	1 stitch ~7 stitch	
	Length of Lock Sti.	0.1		
C21	(mm)	0.6	0.3~1.5	
				Set the lock stitch number at
C19	Lock Num. After	2	0~3	pulling the bar for embroidery
	Irim			after setting the trimming
	Cain Decade for			2 for most machines, 1 for
D06	Spill Koullus for	1	1,2	mini type or machines with
	DIAKE			servo control main shaft motor.
		Y	X Frame-moving, Y	
C23	Action after Trim	Frame-movin	Frame-moving Move	
		g	Needle	
C22	Frame after Trim	No	No, Yes	
D03	Set Hold Startup	-4	-4~3	
200	Para.			
D07	Trim is OK	Yes	No, Yes	
				Set the hook angle by motor.
Dee	Hook Angle by	100	100 100	When user increases the value,
D08	Motor	-100	-100~+100	the hook angle is moved
				backward.



No.	Name of Parameter	Default Value	Range of Value	Remarks
E39	Hook Distance By Motor	150	0~180	
C17	Pause Trimming	No	No, Yes	
C18	Trim Length	3	1~8	1 is the minimum length and 8 are the maximum length.
D05	Speed When Trimming	80	80,90,100,,250	
C20	Lock When Trim	Yes	No, Yes	
D48	Lock Sti Len bef.Trim	0.7	0.3~2	
D49	Lock Sti bef.Trim	2	0~2	
C81	Cut action start angle	8	0~20	It is fit for the machine using stepping-motor for trimming thread.
C82	Cut return angle adj	12	0~30	The same as above.
C83	Cut keeper return angle	0	0~99	The same as above.
C84	Hold voltage adj	1	1~3	The same as above.
C95	Speed At 1st Sti. Bef. Trim	400	60~600	
C96	Speed At 2st Sti. Bef. Trim	80	60~500	
C93	When the shear line surface	Open	Open, 1 times, 2times	
C94	Emb surface clip action way	Open	Open, 1 times, 2times	
E99	Patch emb surface when fully	No	No, Yes	
1105	Trimming device	Stepping	Stepping motor,	
П03	type	motor	Solenoid	
C110	Trim Machine Type	360	180, 360	The same as above.
P06	Stepping hook speed	3	0~5	
P07	Stepping shearing stroke	115	40~180	
	Sequin	Parameters	(Applicable for JF S	Sequin)
C31	Speed for Sequin R	400	300,310, ··· ,the maximum speed	



No.	Name of Parameter	Default Value	Range of Value	Remarks
C32	Speed for Sequin L	400	300,310, ··· , the maximum speed	
D25	Sequin R Adj. Angle	0	-15~15	
D26	Sequin L Adj. Angle	0	-15~15	
C33	Auto Start for Sequin	No	No, Yes	
D27	Time of Sequin Action	3	0~15	Range: 0-15. For the machine using valve to move the presser, this parameter is generally set at 2~3. For the machine using stepping motor to move the presser, this value is set at 4~5.
C34	Sequin Up after T.B.	No	No, Yes	It is used to control the position of the sequin device after thread-breakage
C56	Sequin Ind. Up Down	No	No, Yes	
B17	Up Valve When Jump & No cut	Yes	No, Yes	
D61	Motor Number of L Sequin		No,1~4,1(2~4)	Set the parameter base on sequin device. 2~4 mean device number driven by one motor
D54	Motor Number of R Sequin		No,1~4,1(2~4)	Set the parameter base on sequin device. 2~4 mean device number driven by one motor
D84	L Knife Start Angle Adj	1	0~31	
D83	R Knife Start Angle Adj	1	0~31	
D99	R.Knife Start Angle Adj.	2	0~10	
D55	Set 3MM of R Sequin	Double-ways /11.7	One-way $5.4 \sim 62.2$ angle; Double-ways $5.4 \sim 62.2$ angle	
D56	Set 4MM of R Sequin	Double-ways /11.7	One-way $5.4 \sim 62.2$ angle; Double-ways $5.4 \sim 62.2$ angle	



No.	Name of Parameter	Default Value	Range of Value	Remarks
	Set 5MM of R	Double-ways	One-way 5.4 ~ 62.2	
D57	Sequin		angle; Double-ways	
	Sequin	/10	5.4~62.2 angle	
	Set 6 75MM of R	Double-ways	One-way 5.4 $\sim~62.2$	
D58	Sequin	/21.6	angle; Double-ways	
	Sequin	/21.0	5.4~62.2 angle	
	Set 9MM of R	Double-ways	One-way 5.4 $\sim~62.2$	
D59	Sequin	/36	angle; Double-ways	
	Soquin	, 20	$5.4 \sim 62.2$ angle	
			3/4/5/6.75/9mm	
C57	A Size&Color of R	4mm vellow	Light gray/gold/red	
057	Sequin	inini yenow	/green/blue/purple/yell	
			ow/cyanogen	
			3/4/5/6.75/9mm	
C58	B Size&Color of R	4mm blue	Light gray/gold/red	
000	Sequin	4mm onde	/green/blue/purple/yell	
			ow/cyanogen	
			3/4/5/6.75/9mm	
C59	C Size&Color of R	5mm	Light gray/gold/red	
0.57	Sequin	cyanogen	/green/blue/purple/yell	
			ow/cyanogen	
			3/4/5/6.75/9mm	
C60	D Size&Color of R	6.75mm gold	Light gray/gold/red	
000	Sequin	0.75mm gold	/green/blue/purple/yell	
			ow/cyanogen	
	Set 3MM of L		One-way 5.4 $\sim~62.2$	
D62	Sequin		angle; Double-ways	
	Sequin		$5.4 \sim 62.2$ angle	
	Set 4MM of L		One-way 5.4 $\sim~62.2$	
D63	Sequin		angle; Double-ways	
	Soquin		$5.4 \sim 62.2$ angle	
	Set 5MM of L		One-way 5.4 $\sim~62.2$	
D64	Sequin		angle; Double-ways	
			$5.4 \sim 62.2$ angle	
	Set 6.75MM of L		One-way 5.4 $\sim~62.2$	
D65	Sequin		angle; Double-ways	
	~ • 1		$5.4 \sim 62.2$ angle	
	Set 9MM of L		One-way 5.4 ~ 62.2	
D66	Sequin		angle; Double-ways	
			5.4~62.2 angle	
C61	A Size&Color of L	3mm vellow	3/4/5/6.75/9mm	
2.51	Sequin		Light gray/gold/red	



No.	Name of Parameter	Default Value	Range of Value	Remarks
			/green/blue/purple/yell	
			ow/cyanogen	
C62	B Size&Color of L Sequin	4mm blue	3/4/5/6.75/9mm Light gray/gold/red /green/blue/purple/yell ow/cyanogen	
C63	C Size&Color of L Sequin	5mm purple	3/4/5/6.75/9mm Light gray/gold/red /green/blue/purple/yell ow/cyanogen	
C64	D Size&Color of L Sequin	6.75mm gold	3/4/5/6.75/9mm Light gray/gold/red /green/blue/purple/yell ow/cyanogen	
JF01	RightCuttingRange	15	0~31	
JF02	Left Cutting Range	15	0~31	
JF03	Right Sequine Select	All	All, Direct AB, Side CD	
JF04	Left Sequine Select	All	All, Direct AB, Side CD	
JF05	Start Angle of Right Cutter	15	0~31	
JF06	Start Angle of Left Cutter	15	0~31	
JF07	InsertEmptyNeddleBeforeSequinImage: Sequin state	No	Yes, No	
JF08	Sequin Device Life Mode	Independen	Independen, Concentrate	
D67	Sequin Gap Num of L Sequin	No	No, 1,2	
C66	Valve Time of Left Sequin	0	0~5	
D98	L.Knife Start Angle Adj.	15	0~31	
D60	Sequin Gap Num of R Sequin	No	No, 1,2	
C65	Valve Time of Right Sequin	0	0~5	



No.	Name of Parameter	Default Value	Range of Value	Remarks	
Taping Parameter					
D86	A-Zig Emb.Right On/Off	Yes	Yes(First Stitch), No		
D87	A-Zig Emb.Left On/Off	Yes	Yes(Last Stitch), No		
D88	A-Zig Emb. On/Off Time	2			
C35	A-Zig Max Speed	400	300~850		
D29	A-Zig Swing Angle	0	0~125		
C38	A-Zig 5 Swing Angle	0.2	0.2~10		
D93	A-Zig T.L Adj	5	0~10		
D95	A-TAPING Emb.righe origin pos.	0	0~100		
D96	A-TAPING Emb.left origin pos.	0	0~100		
D81	A-Zig great efficiency mode	5	1~5		
ST01	Work mode	2	1~5		
ST02	Actuation time adj.	1	1~20		
ST03	Looped time	50	30~100		
ST04	Whether cut line when jump	No	Yes, No		
D92	A-Zig Has Loosing-Motor	Yes	Yes, No		
D97	A-TAPING Up&Down Detect.	No	No, Yes		
GlassBead Parameters					
E80	Send beads angle for motor L	30	1~100		
E81	Recv beads angle for motor L	50	1~50		
E82	Angle for L clip motor	30	1~50		
E83	Adj speed of L soeed motor	8	0~15		
E84	Adj speed of L	8	0~15		



No.	Name of Parameter	Default Value	Range of Value	Remarks
	conveyor motor			
E85	Adj speed of L add-power motor	8	0~15	
E86	Time para for L bead	24	1~50	
E87	Time para for L sequin	15	1~50	
E88	Count of L bead motor	None	None, Yes	
GB02	Left Bead Turntable Action Time	5	1~10	
E89	Send beads angle for motor R	61	1~100	
E90	Recv beads angle for motor R	10	1~50	
E91	Angle for R clip motor	18	1~50	
E92	Adj speed of R soeed motor	8	0~15	
E93	Adj speed of R conveyor motor	8	0~15	
E94	Adj speed of R add-power motor	8	0~15	
E95	Time para for R bead	24	1~50	
E96	Time para for R sequin	15	1~50	
E97	Count of R bead motor	None	None, Yes	
GB03	Right Bead Turntable Action Time	5	1~10	
E98	All head change bead cnt	0	1~2500	
H03	Angle of glass-bead arriving	0	0~359	
H04	Bead more revolutions	8	0~15	
GB04	Whether to insert bead code or not	No	No, Yes	



No.	Name of Parameter	Default Value	Range of Value	Remarks
		Taping Em	broidery Parameter	
C55	M Axis Origin At T.B.	Yes	No, Yes	
C54	Cord Emb. Needle	Yes	No, Yes	
C37	M Axis Stop to Origin	Yes	No, Yes	
D28	Special Head Interval	10	10~1000	
D30	Clamp Foot Displace	0	0~90	
D40	Adj Clamp Foot Limit	170	0~250	
B16	Clamp Foot Min Height Adj	0	0~255	
D31	Rod Pos. of Zigzag	Left	Left/Right	
D29	Zigzag Swing Angle	90	0~90	
C38	Swing Value of Zigzag	0.2	0~10	
D50	Adj Z Emb Swing	0	0~5	
D42	Rotary Gap of M Axis	0	0~10	
D44	M Axis Work OFF Angle	0	0, 90	
C39	Spec. Emb. Trim Mode	No Trim	Low, Above & Low, No Trim	
C35	Speed for Sequin L	400	300~850	
C51	Spec Minimum Speed	250	250~400	
C52	Spec. Speed-Down Angle	30	1~180	
C53	Spec. Speed-Down Ratio	1	1~4	
D39	Z Shift Control Angle	0	0~180	
D41	Adj Zigzag Rod Angle	3	1,2,3	
C36	Ratio of Coil Emb.	1 Sti/L	1~4 Sti/L	
D47	Slow Down When	Yes	No, Yes	



No.	Name of Parameter	Default Value	Range of Value	Remarks
	Coil Emb			
		Machi	ne Parameters	
D01	Needles	6	1,2,,MAXNEEDLE	Set the value according to the machine situation. E.g. the value should be 9 for 9-needle machine. If the value is different from the machine needles, the color changing will be abnormal.
D12	Color-Change Speed	12	0~30	
K2	Openloop stepper change color curve	0	0~7	
C43	IP Address			It is used for setting machine address when connected to PC. It is not different among different machines.
C45	Subnet mask			It is used for setting the subnet mask of IP address when connected to PC.
C46	Gateway			It is used for setting the gateway of machine when connected to PC.
Z02	DNS Server			
Z03	Start DHCP	No	No, Yes	
C49	X compensation for mechanical gap	0	0,1	
C50	Y compensation for mechanical gap	0	0,1	
C29	Needle of Boring	No	No, 1~7	
C71	Thread hold voltage adj.	1	1~10	
E1	DIP1	0	0~255	
E2	DIP2	0	0~255	
E3	DIP3	0	0~255	
E4	DIP4	0	0~255	
H06	Drive failure monitoring	Yes	No, Yes	
M100	Start needle light	No	No, Yes	
К3	Hat emb Speed limit	800	80~800	



No.	Name of Parameter	Default Value	Range of Value	Remarks		
D68	Number of heads	1	1~10			
E45	Machine head distance	162	1~1500			
C29	Carving Needle Pos.	None	None, 1~7			
C30	Boring Emb. Disp.	0	0~12			
Y001	X/Y Limit Position	X Right Y Back	X Right Y Back, X Right Y Front, X Left Y Back, X Left Y Front,			
Y002	X/Y Limit Origion	X+Y+	X+Y+, X+Y-, X-Y+, X-Y-			
Y003	X/Y Limit Origion Detection Mode	X Double Y Double	X Double Y Double, X Double Y Single, X Single Y Double, X Single Y Single			
Z01	Turn on infrared protection	No	No, Yes			
P01	Head spacing of punching machiine	28	10~1000			
P02	Number of needles in punching machiine	12	1~15			
		Net	Parameters			
C47	Machine Number	1	1~245			
C41	Server Port	1600	1~9999	It is used for setting sever port when it is connected to PC.		
C42	MAC Address	00112233445 5	001111111111~00999 9999999	It is used for setting the MAC address of embroidery machine network card. The address is different at different machine.		
	PC2220 Set					
P01	Color motor current	2	0~3			
P02	Trim motor current	2	0~3			
P03	Hook motor current	2	0~3			
P04	Head motor current	2	0~3			



No	Operations	Methods or Standards	Remarks
1	USB I/O	Same as floppy disk	
2	Operation priority between USB disk and floppy disk	USB Disk	
3	Format supported by USB disk	FAT16 and FAT32	
4	Support long file name	Support, but not displayed	
5	File name format	DOS 8.3 mode (8 digit prefix is viewable, suffix is 3 digits)	For instance: "清明 上河图.DST" will be displayed as "清 明上~1.DST"
6	Support file name in Chinese	Support	
7	Sub-directory operation	Support	
8	Sub-directory limitation	No. It could be countless in theory	
9	File number in one sub-directory	400	
10	Reading & writing error/ change USB	Back to disk management or design management interface, insert the disk again.	
11	Multi-logical disks in one USB	Support	
12	Formatting USB	Support	
13	Installation of the letter base	Not Support	
14	Software update	Support	
15	Special character in file name	Support, except "\$".	

Appendix 2 Directions of U Disk Operation



Appendix 3 Automatic Position Limitation Function Instructions for Apparel Embroidery

A、Working Principle

The automatic position limitation function of single-head embroidery machine controller is to determine the embroidery range of the frame by setting the distance from the center of the frame to the origin (that is X-/Y position limitation optical coupler) and the actual frame size (unit: mm). If embroidery is to be done beyond such range, the controller will activate automatic protection to prevent damage to the mechanical parts of the embroidery machine.

$B_{\,{\scriptscriptstyle \nabla}}\,$ Setting Method







4. Clear the XY Displacement



5. Manual Frame-moving



In the frame parameter setting interface, click the frame-moving key to move the frame to overlap its center with the needle hole.



6. Set Frame Center and Size

In the frame parameter setting interface, check the coordinates of XY, which is the position of frame center.

× 🕄	(D)	DAHAO 14:19 2020-06-16			
1	> 🎎 🖉	> // = 1\ 3 > 👥 «			
Frame A F	rame B Frame C	Frame D Frame E Frame F			
Frame G F	rame H Frame I	Frame J			
Formation and the	2000				
Frame Length	3000				
Frame Width	3000	Hide Frame			
Frame Chamfer	0	X:34 Y:-31			
Pattern Rotate 180					
(Cap Emb)		X 65 Y -60			
Param Related Garment param					
Frame A 3000X3000					

Press " key, where user can input the coordinates of XY in the frame parameter setting interface.





There are four parameters: "X direction center" means the distance at X direction between the frame center and X- direction position limitation optical coupler; "Y direction center" means the distance at Y direction between the frame center and Y+ direction position limitation optical coupler. "X direction frame size" means the embroidery range of the frame at X direction; "Y direction frame size" means the embroidery range of the frame at Y direction.



"X direction frame size" and "Y direction frame size" should be set according to the actual size of different frames. Note: this parameter need be set according to the actual embroidery range of the frame, for the apparel frame is usually not square.





C、Cancel Position Limitation

Set "Frame Selection" as "No Frame", the position limitation function will be canceled and the software protection for the frame of flat embroidery will also become invalid.





D、Common Frame Size (Unit: mm) Frame 1: Size: 550×375 Embroidery Range: 430×260



Frame 3: Size: 200 Embroidery Range: 150



Frame 5: Size: 120 Embroidery Range: 90 Frame 2: Size: 290×290 Embroidery Range: 230×230



Frame 4: Size: 150 Embroidery Range: 100



Frame 6: Size: 90 Embroidery Range: 40







If user, after releasing embroidery confirmation, wants to embroidery the pattern again, user need operate from step B "Select Pattern for Embroidery" again.

Part II. Manual Operation

A. Manual Trimming



D. Manual Frame-moving

Direction Keys: (a), (b), (c), (c); Speed Shift Key: (b)

E. Empty Feed

1. Empty Feed and Return at Low Speed



3. Locate the Last Color-changing Code



4. Locate the Next Color-changing Code





C. Main Shaft Jog



2. Empty Feed and Advance at low Speed

0+/-) → [**0+**] ([**0**++), [**0+**→]

5. Empty Feed and Return at High Speed



6. Empty Feed and Advance at High Speed



7. Return to Embroidery Start Point



8. Return to Embroidery Stop Point

