

Data-Stitch Inc.
Toyota AD 850,860 and 851

Basic User's Guide

Covers the basics to operating the Toyota
AD 850, 860 and 851

Reading Design into machine memory

- 1.) Press the START POINT key
- 2.) Press the DATA key
- 3.) Press the SET key
- 4.) Press the 1 key (or other number per your computer instruction)
- 5.) Press the SET key

If you using disk reader on your TOYOTA 860, the disk reader must be plug into the machine before turn the machine ON. To read from the disk press de DATA key until READING DISK appears on the control panel. To read from the computer press the DATA key until INPUT TO PC appears on control panel.

Note: The green light should being flashing. This indicates that design is being transferred from the computer to the machine. The machine will beep and the green light will go out when the transfer of the design data is complete.

Checking the size of the design

- 1.) Press the START POINT key
- 2.) Use the ←, →, ↑ or ↓ arrow to select the starting location.
- 3.) Press the TRACE key
- 4.) The frame will move from the origin to the outermost design limits and then back to the origin.

Note: The design must be completely loaded into the machine before using the function

Checking the size of the design

- 1.) Press the START POINT key
- 2.) Use the ←, →, ↑ or ↓ arrow to select the starting location.
- 3.) Press the TRACE key
- 4.) The frame will move from the origin to the outermost design limits and then back to the origin.

Note: The design must be completely loaded into the machine before using the function

Setting of automatic color changes

- 1.) Once you have transferred the design into the machine simply enter the desired colors by their corresponding numbers into the machine. Note: Press the 10+ key then 0 key the color change to 10 the machine display A for color 10, B for color 11 and C for color 12.
- 2.) Press the SET key

Setting of Manual color changes

- 1.) Press the A\M key
- 2.) Use the ← and → arrows to select the color
- 3.) Press the SET key

Note: None of the information on this page applies to TOYOTA AD 851

Moving forward stitch by stitch

- 1.) Press the F1 key
- 2.) Select the option FORW\BACK
- 3.) Press the → arrow key until 1ST appears
- 4.) Press the SET key

Moving forward color by color

- 1.) Press the F1 key
- 2.) Press the → arrow until COL appears
- 3.) Press the SET key

Deleting individual design from machine memory

- 1.) Press the START POINT key
- 2.) Press the DATA key
- 3.) Use the ↓ arrow to highlight number –3
DELETE DESIGN
- 4.) Press the SET key
- 5.) Use the ↑ and ↓ arrows to select the design
data number
- 6.) Press the SET key

Deleting all designs from memory

- 1.) Press the START POINT key
- 2.) Press the DATA key
- 3.) Use the ↓ arrow to highlight number -4
INITIALIZE MEMORY
- 4.) Press the SET key twice

Note: This needs to be done quite frequently or you may receive error transferring designs from the computer to the machine.
